National Semiconductor

# ADC12048 12-Bit Plus Sign 216 kHz 8-Channel Sampling Analog-to-Digital Converter

# **General Description**

Operating from a single 5V power supply the ADC12048 is a 12 bit  $\pm$  sign, parallel I/O, self-calibrating, sampling analog-to-digital converter (ADC) with an eight input fully differential analog multiplexer. The maximum sampling rate is 216 kHz. On request, the ADC goes through a self-calibration process that adjusts linearity, zero and full-scale errors.

The ADC12048's 8-channel multiplexer is software programmable to operate in a variety of combinations of singleended, differential, or pseudo-differential modes. The fully differential MUX and the 12-bit + sign ADC allows for the difference between two signals to be digitized.

The ADC12048 can be configured to work with many popular microprocessors/microcontrollers including National's HPC family, Intel386 and 8051, TMS320C25, Motorola MC68HC11/16, Hitachi 64180 and Analog Devices ADSP21xx.

For complementary voltage references see the LM4040, LM4041 or LM9140.

## Key Specifications (f<sub>CLK</sub> = 12 MHz)

- Resolution
- 13-bit conversion time
- 13-bit throughput rate
- Integral Linearity Error (ILE)

 Single Supply +5V ±10%
 V<sub>IN</sub> Range GND to V<sub>A</sub>+
 Power consumption: Normal operation 34 mW, max Stand-by mode 75 μw, max

## Features

- 8-channel programmable Differential or Single-Ended multiplexer
- Programmable Acquisition Times and user-controllable Throughput Rates
- Programmable data bus width (8/13 bits)
- Built-in Sample-and-Hold
- Programmable Auto-Calibration and Auto-Zero cycles
- Low power standby mode
- No missing codes

## Applications

- Medical instrumentation
- Process control systems
- Test equipment

12-bits + sign

±1 LSB, max

216 ksamples/s, min

3.6 µs, max

- Data logging
- Inertial guidance



© 1996 National Semiconductor Corporation TL/H/12387

RRD-B30M26/Printed in U. S. A

ADC12048 12-Bit Plus Sign 216 kHz 8-Channel Sampling Analog-to-Digital Converte

December 1995



# Absolute Maximum Ratings (Notes 1 and 2)

If Military/Aerospace specified devices are required, please contact the National Semiconductor Sales Office/Distributors for availability and specifications.

Supply Voltage ( $V_A^+$ and $V_D^+$ )	6.0V
Voltage at all Inputs	$-$ 0.3V to V $^+$ + 0.3V
$ V_A^+ - V_D^+ $	300 mV
AGND – DGND	300 mV
Input Current at Any Pin (Note 3)	$\pm$ 30 mA
Package Input Current (Note 3)	$\pm$ 120 mA
Power Dissipation (Note 4)	
at $T_A = 25^{\circ}C$	875 mW
Storage Temperature	-65°C to +150°C

Lead Temperature VF Package	
Vapor Phase (60 sec.)	210°C
Infared (15 sec.)	220°C
V Package, Infared (15 sec.)	300°C
ESD Susceptibility (Note 5)	3.0 kV

# Operating Ratings (Notes 1 and 2)

Temperature Range	
$(T_{min} \le T_A \le T_{max})$	$-40^{\circ}C \leq T_{A} \leq 85^{\circ}C$
Supply Voltage	
$V_A^+, V_D^+$	4.5V to 5.5V
$ V_{A}^{+} - V_{D}^{+} $	$\leq$ 100 mV
AGND - DGND	$\leq$ 100 mV
V <sub>IN</sub> Voltage Range at all Inp	buts $GND \le V_{IN} \le V_A^+$
V <sub>REF</sub> <sup>+</sup> Input Voltage	$1V \leq V_{REF}^+ \leq V_{A}^+$
V <sub>REF</sub> <sup>-</sup> Input Voltage	$0 \leq V_{REF}^- \leq V_{REF}^+ - 1V$
$V_{REF}^+ - V_{REF}^-$	$1V \le V_{REF} \le V_{A}^+$
V <sub>REF</sub> Common Mode	0.1 $V_{\text{A}}{}^+  \leq V_{\text{REFCM}} \leq$ 0.6 $V_{\text{A}}{}^+$

**Converter DC Characteristics** The following specifications apply to the ADC12048 for  $V_A^+ = V_D^+ = 5V$ ,  $V_{REF}^+ = 4.096V$ ,  $V_{REF}^- = 0.0V$ , 12-bit + sign conversion mode,  $f_{CLK} = 12.0$  MHz,  $R_S = 25\Omega$ , source impedance for  $V_{REF}^+$  and  $V_{REF}^- \le 1\Omega$ , fully differential input with fixed 2.048V common-mode voltage ( $V_{INCM}$ ), and minimum acquisition time, unless otherwise specified. **Boldface limits apply for T\_A = T\_J = T\_{MIN} to T\_MAX;** all other limits  $T_A = T_J = 25^{\circ}C$ 

Symbol	Parameter	Conditions	Typical (Note 10)	Limits (Note 11)	Unit (Limit)
	Resolution with No Missing Codes	After Auto-Cal		13	Bits (max)
ILE	Positive and Negative Integral Linearity Error	After Auto-Cal (Notes 12 and 17)	±0.6	± 1	LSB (max)
DNL	Differential Non-Linearity	After Auto-Cal		± 1	LSB (max)
	Zero Error	$\begin{array}{l} \mbox{After Auto-Cal (Notes 13 and 17)} \\ V_{INCM} = 5.0V \\ V_{INCM} = 2.048V \\ V_{INCM} = 0V \end{array}$		± 5.5 ± 2.5 ± 5.5	LSB (max)
	Positive Full-Scale Error	After Auto-Cal (Notes 12 and 17)	±1.0	± 2.5	LSB (max)
	Negative Full-Scale Error	After Auto-Cal (Notes 12 and 17)	±1.0	± 2.5	LSB (max)
	DC Common Mode Error	After Auto-Cal (Note 14)	±2	± 5.5	LSB (max)
TUE	Total Unadjusted Error	After Auto-Cal (Note 18)	±1		LSB

**Power Supply Characteristics** The following specifications apply to the ADC12048 for  $V_A^+ = V_D^+ = 5V$ ,  $V_{REF}^+ = 4.096V$ ,  $V_{REF}^- = 0.0V$ , 12-bit + sign conversion mode,  $f_{CLK} = 12.0$  MHz,  $R_S = 25\Omega$ , source impedance for  $V_{REF}^+$  and  $V_{REF}^- \le 1\Omega$ , fully differential input with fixed 2.048V common-mode voltage, and minimum acquisition time, unless otherwise specified. **Boldface limits apply for T<sub>A</sub> = T<sub>J</sub> = T<sub>MIN</sub> to T<sub>MAX</sub>; all other limits T<sub>A</sub> = T<sub>J</sub> = 25°C** 

	•				
Symbol	Parameter	Conditions	Typical (Note 10)	Limits (Note 11)	Unit (Limit)
PSS	Power Supply Sensitivity	$V_{D}^{+} = V_{A}^{+} = 5.0V \pm 10\%$			
	Zero Error	$V_{\text{REF}}^{+} = 4.096 V$	±0.1		LSB
	Full-Scale Error	$V_{REF}^{-} = 0V$	±0.5		LSB
	Linearity Error		±0.1		LSB
$I_D^+$	V <sub>D</sub> <sup>+</sup> Digital Supply Current	Start Command (Performing a conversion) with SYNC configured as an input and driven with a 214 kHz signal. Bus width set to 13.			
		f <sub>CLK</sub> = 12.0 MHz, Reset Mode	850		μΑ
		f <sub>CLK</sub> = 12.0 MHz, Conversion	2.45	2.8	mA (max)
$I_A^+$	V <sub>A</sub> <sup>+</sup> Analog Supply Current	Start Command (Performing a conversion) with SYNC configured as an input and driven with a 214 kHz signal. Bus width set to 13.			
		f <sub>CLK</sub> = 12.0 MHz, Reset Mode	2.3		mA
		f <sub>CLK</sub> = 12.0 MHz, Conversion	2.3	4.0	mA (max)
IST	Standby Supply Current	Standby Mode			
	$(I_{D}^{+} + I_{A}^{+})$	f <sub>CLK</sub> = Stopped	5	15	μA (max)
		$f_{CLK} = 12.0 \text{ MHz}$	100	120	μA (max)

**Analog MUX Inputs Characteristics** The following specifications apply to the ADC12048 for  $V_A^+ = V_{D+} = 5V$ ,  $V_{REF}^+ = 4.096V$ ,  $V_{REF}^- = 0.0V$ , 12-Bit + sign conversion mode,  $f_{CLK} = 12.0$  MHz,  $R_S = 25\Omega$ , source impedance for  $V_{REF}^+$  and  $V_{REF}^+ \le 1\Omega$ , fully differential input with fixed 2.048V common-mode voltage, and minimum acquisition time, unless otherwise specified. **Boldface limits apply for T\_A = T\_J = T\_{MIN} to T\_MAX;** all other limits  $T_A = T_J = 25^{\circ}C$ 

Symbol	Parameter	Conditions	Typical (Note 10)	Limits (Note 11)	Unit (Limit)
I <sub>ON</sub>	MUX ON Channel Leakage Current	ON Channel = 5V, OFF Channel = 0V ON Channel = 0V, OFF Channel = 5V	0.05 0.05	1.0 - 1.0	μΑ (min) μΑ (max)
IOFF	MUX OFF Channel Leakage Current	ON Channel = 5V, OFF Channel = 0V ON Channel = 0V, OFF Channel = 5V	0.05 0.05	1.0 - 1.0	μΑ (min) μΑ (max)
IADCIN	ADCIN Input Leakage Current		0.05	2.0	μA (max)
R <sub>ON</sub>	MUX On Resistance	$V_{IN} = 2.5V$	310	500	$\Omega$ (max)
	MUX Channel-to-Channel R <sub>ON</sub> Matching	$V_{IN} = 2.5V$	±20%		Ω
C <sub>MUX</sub>	MUX Channel and COM Input Capacitance		10		pF
C <sub>ADC</sub>	ADCIN Input Capacitance		70		pF
C <sub>MUXOUT</sub>	MUX Output Capacitance		20		pF

**Reference Inputs** The following specifications apply to the ADC12048 for  $V_A^+ = V_D^+ = 5V$ ,  $V_{REF}^+ = 4.096V$ ,  $V_{REF}^- = 0.0V$ , 12-bit + sign conversion mode,  $f_{CLK} = 12.0$  MHz,  $R_S = 25\Omega$ , source impedance for  $V_{REF}^+$  and  $V_{REF}^- \le 1\Omega$ , fully differential input with fixed 2.048V common-mode voltage, and minimum acquisition time, unless otherwise specified. Boldface limits apply for  $T_A = T_J = T_{MIN}$  to  $T_{MAX}$ ; all other limits  $T_A = T_J = 25^{\circ}C$ 

Symbol	Parameter	Conditions	Typical (Note 10)	Limits (Note 11)	Unit (Limit)
IREF	Reference Input Current	$V_{REF}^{+}$ 4.096V, $V_{REF-}^{-}$ = 0V Analog Input Signal: 1 kHz (Note 20) 80 kHz	145 136		μΑ μΑ
C <sub>REF</sub>	Reference Input Capacitance		85		pF

**Digital Logic Input/Output Characteristics** The following specifications apply to the ADC12048 for  $V_A^+ = V_D^+ = 5V$ ,  $V_{REF}^+ = 4.096V$ ,  $V_{REF}^- = 0.0V$ , 12-bit + sign conversion mode,  $f_{CLK} = 12.0$  MHz,  $R_S = 25\Omega$ , source impedance for  $V_{REF}^+$  and  $V_{REF}^- \le 1\Omega$ , fully differential input with fixed 2.048V common-mode voltage, and minimum acquisition time, unless otherwise specified. **Boldface limits apply for T\_A = T\_J = T\_{MIN} to T\_MAX;** all other limits  $T_A = T_J = 25^{\circ}C$ 

Symbol	Parameter	Conditions	Typical (Note 10)	Limits (Note 11)	Unit (Limit)
V <sub>IH</sub>	Logic High Input Voltage	$V_{A}^{+} = V_{D}^{+} = 5.5V$		2.0	V (min)
V <sub>IL</sub>	Logic Low Input Voltage	$V_{A}^{+} = V_{D}^{+} = 4.5V$		0.8	V (max)
I <sub>IH</sub>	Logic High Input Current	$V_{IN} = 5V$	0.035	2.0	μA (max)
IIL	Logic Low Input Current	$V_{IN} = 0V$	-0.035	-2.0	μA (max)
V <sub>OH</sub>	Logic High Output Voltage	$V_{A}^{+} = V_{D}^{+} = 4.5V$ $I_{OUT} = -1.6 \text{ mA}$		2.4	V (min)
V <sub>OL</sub>	Logic Low Output Voltage	$V_{A}^{+} = V_{D}^{+} = 4.5V$ $I_{OUT} = 1.6 \text{ mA}$		0.4	V (max)
I <sub>OFF</sub>	TRI-STATE® Output Leakage Current	$V_{OUT} = 0V$ $V_{OUT} = 5V$		± 2.0	μA (max)
C <sub>IN</sub>	D12-D0 Input Capacitance		10		pF

**Converter AC Characteristics** The following specifications apply to the ADC12048 for  $V_S^+ = V_D^+ = 5V$ ,  $V_{REF}^+ = 4.096V$ ,  $V_{REF}^- = 0.0V$ , 12-bit + sign conversion mode,  $f_{CLK} = 12.0$  MHz,  $R_S = 25\Omega$ , source impedance for  $V_{REF}^+$  and  $V_{REF}^- \le 1\Omega$ , fully differential input with fixed 2.048V common-mode voltage, and minimum acquisition time, unless otherwise specified. **Boldface limits apply for T\_A = T\_J = T\_{MIN} to T\_{MAX}; all other limits T\_A = T\_J = 25^{\circ}C** 

Symbol	Parameter	Conditions	Typical (Note 10)	Limits (Note 11)	Unit (Limit)
t <sub>Z</sub>	Auto Zero Time		78	78 ciks + 120 ns	clks (max)
t <sub>CAL</sub>	Full Calibration Time		4946	4946 clks + 120 ns	clks (max)
	CLK Duty Cycle		50	40 60	% % (min) % (max)
t <sub>CONV</sub>	Conversion Time	Sync-Out Mode	44	44	clks (max)
t <sub>AcqSYNCOUT</sub>	Acquisition Time (Programmable)	Minimum for 13 Bits Maximum for 13 Bits	9 79	9 clks + 120 ns 79 clks + 120 ns	clks (max) clks (max)

Symbol <i>(Figure 7)</i>	Parameter	Conditions	Typical (Note 10)	Limits (Note 11)	Units (Limit)
t <sub>TPR</sub>	Throughput Rate	Sync-Out Mode (SYNC Bit = "0") 9 Clock Cycles of Acquisition Time	222		kHz
t <sub>CSWR</sub>	Falling Edge of $\overline{\text{CS}}$ to Falling Edge of $\overline{\text{WR}}$		0		ns
t <sub>WRCS</sub>	Active Edge of $\overline{WR}$ to Rising Edge of $\overline{CS}$		0		ns
t <sub>WR</sub>	WR Pulse Width		20	30	ns (min)
tWRSETFalling	Write Setup Time	WMODE = "1"		20	ns (min)
twRHOLDFalling	Write Hold Time	WMODE = "1"		5	ns (min)
t <sub>WRSETRising</sub>	Write Setup Time	WMODE = "0"		20	ns (min)
twRHOLDRising	Write Hold Time	WMODE = "0"		5	ns (min
t <sub>CSRD</sub>	Falling Edge of $\overline{CS}$ to Falling Edge of $\overline{RD}$		0		ns
t <sub>RDCS</sub>	Rising Edge of $\overline{\text{RD}}$ to Rising Edge of $\overline{\text{CS}}$		0		ns
<sup>t</sup> RDDATA	Falling Edge of $\overline{\text{RD}}$ to Valid Data	8-Bit Mode (BW Bit = "0")	40	58	ns (max
t <sub>RDDATA</sub>	Falling Edge of $\overline{RD}$ to Valid Data	13-Bit Mode (BW Bit = "1")	26	44	ns (max
t <sub>RDHOLD</sub>	Read Hold Time		23	32	ns (max
t <sub>RDRDY</sub>	Rising Edge of $\overline{RD}$ to Rising Edge of $\overline{RDY}$		24	38	ns (max
tWRRDY	Active Edge of $\overline{WR}$ to Rising Edge of $\overline{RDY}$	WMODE = "1"	42	65	ns (max
<sup>t</sup> STNDBY	Active Edge of $\overline{\text{WR}}$ to Falling Edge of STDBY	WMODE = "0". Writing the Standby Command into the Configuration Register	200	230	ns (max
<sup>t</sup> STDONE	Active Edge of $\overline{\text{WR}}$ to Rising Edge of STDBY	WMODE = "0". Writing the RESET Command into the Configuration Register	30	45	ns (max
t <sub>STDRDY</sub>	Active Edge of $\overline{WR}$ to Falling Edge of $\overline{RDY}$	WMODE = "0". Writing the RESET Command into the Configuration Register	1.4	2.5	ms (max
tSYNC	Minimum SYNC Pulse Width		5	10	ns (mir

# **Notes on Specifications**

Note 1: Absolute Maximum Ratings indicate limits beyond which damage to the device may occur. Operating Ratings indicate conditions for which the device is functional, but do not guarantee specific performance limits. For guaranteed specifications and test conditions, see the Electrical Characteristics. The guaranteed specifications apply only for the test conditions listed. Some performance characteristics may degrade when the device is not operated under the listed test conditions.

Note 2: All voltages are measured with respect to GND, unless otherwise specified.

Note 3: When the input voltage ( $V_{IN}$ ) at any pin exceeds the power supply rails ( $V_{IN} < \text{GND or } V_{IN} > (V_A^+ \text{ or } V_D^+)$ ), the current at that pin should be limited to 30 mA. The 120 mA maximum package input current limits the number of pins that can safely exceed the power supplies with an input current of 30 mA to four. Note 4: The maximum power dissipation must he derated at elevated temperatures and is dictated by  $T_{Jmax}$ . (maximum junction temperature),  $\theta_{JA}$  (package junction to ambient thermal resistance), and  $T_A$  (ambient temperature). The maximum allowable power dissipation at any temperature is  $P_{Dmax} = (T_{Jmax} - T_A)/\theta_{JA}$  or the number given in the Absolute Maximum Ratings, whichever is lower. For this device,  $T_{Jmax} = 150^{\circ}$ C, and the typical thermal resistance ( $\theta_{JA}$ ) of the ADC12048 in the V package, when board mounted, is 55°C/W, and in the VF package, when board mounted, is 67.8°C/W. Note 5: Human body model, 100 pF discharged through 1.5 k $\Omega$  resistor.

6

## Notes on Specifications (Continued)

Note 6: Each input and output is protected by a nominal 6.5V breakdown voltage zener diode to GND; as shown below, input voltage magnitude up to 0.3V above VA<sup>+</sup> or 0.3V below GND will not damage the ADC12048. There are parasitic diodes that exist between the inputs and the power supply rails and errors in the A/D conversion can occur if these diodes are forward biased by more than 50 mV. As an example, if  $V_A^+$  is 4.50  $V_{DC}$ , full-scale input voltage must be  $\leq$  4.55  $V_{DC}$  to ensure accurate conversions.



Note 7: V<sub>A</sub><sup>+</sup> and V<sub>D</sub><sup>+</sup> must be connected together to the same power supply voltage and bypassed with separate capacitors at each V<sup>+</sup> pin to assure conversion/comparison accuracy. Refer to the Power Supply Considerations section for a detailed discussion.

Note 8: Accuracy is guaranteed when operating at  $f_{CLK} = 12$  MHz.

Note 9: With the test condition for V\_{REF} (V\_{REF}^+ - V\_{REF}^-) given as +4.096V, the 12-bit LSB is 1.000 mV.

Note 10: Typicals are at  $T_A = 25^{\circ}C$  and represent most likely parametric norm.

Note 11: Limits are guaranteed to National's AOQL (Average Outgoing Quality Level).

Note 12: Positive integral linearity error is defined as the deviation of the analog value, expressed in LSBs, from the straight line that passes through positive fullscale and zero. For negative integral linearity error, the straight line passes through negative full-scale and zero.

Note 13: Zero error is a measure of the deviation from the mid-scale voltage (a code of zero), expressed in LSB. It is the average value of the code transitions between -1 to 0 and 0 to +1 (see Figure 6).

Note 14: The DC common-mode error is measured with both inputs shorted together and driven from 0V to 5V. The measured value is referred to the resulting output value when the inputs are driven with a 2.5V input.

Note 15: Power Supply Sensitivity is measured after an Auto-Zero and Auto Calibration cycle has been completed with V<sub>A</sub>+ and V<sub>D</sub>+ at the specified extremes. Note 16: V<sub>REFCM</sub> (Reference Voltage Common Mode Range) is defined as  $\left(\frac{V_{REF}^{+} + V_{REF}^{-}}{2}\right)$ 

Note 17: The ADC12048's self-calibration technique ensures linearity and offset errors as specified, but noise inherent in the self-calibration process will result in a repeatability uncertainly of  $\pm 0.20$  LSB.

Note 18: Total Unadjusted Error (TUE) includes offset, full scale linearity and MUX errors.

Note 19: The ADC12048 parts used to gather the information for these curves were auto-calibrated prior to taking the measurements at each test condition. The auto-calibration cycle cancels any first order drifts due to test conditions. However, each measurement has a repeatability uncertainty error of 0.2 LSB. See Note

Note 20: This is a DC average current drawn by the reference input with a full-scale sinewave input. The ADC12048 is continuously converting with a throughput rate of 206 kHz.

Note 21: These typical curves were measured during continuous conversions with a positive half-scale DC input. A 240 ns RD pulse was applied 25 ns after the  $\overline{\text{RDY}}$  signal went low. The data bus lines were loaded with 2 HC family CMOS inputs (CL  $\sim$  20 pF).

Note 22: Any other values placed in the command field are meaningless. However, if a code of 101 or 110 is placed in the command field and the CS. BD and WB go low at the same time, the ADC12048 will enter a test mode. These test modes are only to be used by the manufacturer of this device. A hardware power-off and power-on reset must be done to get out of these test modes.



























PLCC Pkg. Pin Number	PQFP Pkg. Pin Number	Pin Name	Description
6 7 8 9 15 16 17 18	44 1 2 3 9 10 11 12	CH0 CH1 CH2 CH3 CH4 CH5 CH6 CH7	The eight analog inputs to the Multiplexer. Active channels are selected based on the contents of bits b3–b0 of the Configuration register. Refer to section titled MUX for more details.
14	8	СОМ	This pin is another analog input pin used as a pseudo ground when the multiplexer is configured in single-ended mode.
13	7	V <sub>REF</sub> +	Positive reference input. The operating voltage range for this input is $1V \le V_{REF}^+ \le V_{A}^+$ (see <i>Figures 3</i> and 4). This pin should be bypassed to AGND at least with a parallel combination of a 10 $\mu$ F and a 0.1 $\mu$ F (ceramic) capacitors. The capacitors should be placed as close to the part as possible.
12	6	V <sub>REF</sub> -	Negative reference input. The operating voltage range for this input is $0V \le V_{REF}^- \le V_{REF}^+ - 1$ (see Figures 3 and 4). This pin should be bypassed to AGND at least with a parallel combination of a 10 $\mu$ F and a 0.1 $\mu$ F (ceramic) capacitor. The capacitors should be placed as close to the part as possible.
19 21	13 15	MUX OUT - MUX OUT +	The inverting (negative) and non-inverting (positive) outputs of the multiplexer. The analog inputs to the MUX selected by bits b3–b0 of the Configuration register appear at these pins.
20 22	14 16	ADCIN - ADCIN +	ADC inputs. The inverting (negative) and non-inverting (positive) inputs into the ADC.
24	18	WMODE	The logic state of this pin at power-up determines which edge of the write signal (WR) will latch in data from the data bus. If tied low, the ADC12048 will latch in data on the <b>rising</b> edge of the WR signal. If tied to a logic <b>high</b> , data will he latched in on the <b>falling</b> edge of the WR signal. The state of this pin should not be changed after power-up.
25	19	SYNC	The SYNC pin can be programmed as an <b>input</b> or an <b>output</b> . The Configuration register's bit b8 controls the function of this pin. When programmed as an <b>input</b> pin (b8 = 1), a rising edge on this pin causes the ADC's sample-and-hold to hold the analog input signal and begin conversion. When programmed as an <b>output</b> pin (b8 = 0), the SYNC pin goes high when a conversion begins and returns low when completed.
26–31 34–40	20-25 29-34	D0-D5 D6-D12	13-bit Data bus of the ADC12048. D12 is the most significant bit and D0 is the least significant. The BW (bus width) bit the Configuration register (b12) selects between an 8-bit or 13-bit data bus width. When the <b>BW</b> bit is <b>cleared</b> (BW = 0) D7-D0 are active and D12-D8 are always in TRI-STATE. When the <b>BW</b> bit is <b>set</b> (BW = 1), D12-D0 are active.
43	37	CLK	The clock input pin used to drive the ADC12048. The operating range is 0.05 MHz to 12 MHz.
44	38	WR	WR is the active low WRITE control input pin. A logic low on this pin and the $\overline{CS}$ will enable the input buffers of the data pins D12–D0. The signal at this pin is used by the ADC12048 to latch in data on D12–D0. The sense of the WMODE p at power-up will determine which edge of the WR signal the ADC12048 will latch in data. See WMODE pin description.
1	39	RD	RD is the active low read control input pin. A logic low on this pin and CS will enable the active output buffers to drive t data bus.
2	40	CS	CS is the active low Chip Select input pin. Used in conjunction with the WR and RD signals to control the active data bi input/output buffers of the data bus.
3	41	RDY	RDY is an active low output pin. The signal at this pin indicates when a requested function has begun or ended. Refer section Functional Description and the digital timing diagrams for more detail.
4	42	STDBY	This is the standby active low output pin. This pin is low when the ADC12048 is in the standby mode and high when th ADC12048 is out of the standby mode or has been requested to leave the standby mode.
10	4	V <sub>A</sub> +	Analog supply input pin. The device operating supply voltage range is $+5V\pm10\%$ . Accuracy is guaranteed only if the Va <sup>+</sup> and V <sub>D</sub> <sup>+</sup> are connected to the same potential. This pin should be bypassed to AGND with a parallel combination of a 10 $\mu$ F and a 0.1 $\mu$ F (ceramic) capacitor. The capacitors should be placed as close to the supply pins of the part a possible.
11	5	AGND	Analog ground pin. This is the device's analog supply ground connection. It should be connected through a low resistance and low inductance ground return to the system power supply.
32 and 41	26 and 35	V <sub>D</sub> +	Digital supply input pins. The device operating supply voltage range is $+5V \pm 10\%$ . Accuracy is guaranteed only if the V <sub>A</sub> <sup>+</sup> and V <sub>D</sub> <sup>+</sup> are connected to the same potential. This pin should be bypassed to DGND with a parallel combination of a 10 $\mu$ F and a 0.1 $\mu$ F (ceramic) capacitor. The capacitors should be placed as close to the supply pins of the part a possible.
33 and 42	27 and 36	DGND	Digital ground pin. This is the device's digital supply ground connection. It should be connected through a low resistan and low inductance ground return to the system power supply.
ADC12 See NS Numbe	Ackage VA Number 048CIV VREF Package CO Package CH COnnection. CH	$\begin{array}{c} & & & \\$	$\begin{array}{c c c c c c c c c c c c c c c c c c c $

# **Register Bit Description**

# CONFIGURATION REGISTER (Write Only)

This is a 13-bit write-only register that is used to program the functionality of the ADC12048. All data written to the ADC12048 will always go to this register only. The contents of this register cannot be read. MSB LSB

b12         b11         b10         b9         b8         b7         b6         b5         b4           BW         COMMAND         SYNC         HB         SE         ACQ TIME	0 <sub>8</sub> b <sub>7</sub> b <sub>6</sub> b <sub>5</sub>	b <sub>5</sub> b <sub>4</sub> b <sub>3</sub> b <sub>2</sub> b <sub>1</sub>	le .
DW COMMAND SYNC UP SE ACO TIME		-3 -4 -3 -2 -1	b <sub>0</sub>
FIELD STING HB SE ACQ TIME	NC HB SE ACQ	ACQ TIME MUX ADDRESS	

## Power on State: 0100Hex

ba-b<sub>0</sub>: The MUX ADDRESS bits configure the analog input MUX. They select which input channels of the MUX will connect to the MUXOUT+ and MUXOUTpins. (Refer to the **MUX** section for more details on the MUX.) **Power-up** value is 0000.

		b <sub>3</sub>	b <sub>2</sub>		b <sub>1</sub>	b <sub>0</sub>	MUX	DUT+		MUXOUT	-	
		0	0		0	0	С	HO		CH1		1
		0	0		0	1	C	H1		CH0		
		0	0		1	0	С	H2		CH3		
		0	0		1	1	С	H3		CH2		1
		0	1		0	0	С	H4		CH5		1
		0	1		0	1	С	H5		CH4		1
		0	1		1	0	С	H6		CH7		1
		0	1		1	1	С	H7		CH6		1
		1	0		0	0		HO		COM		1
		1	0		0	1		H1		COM		1
		1	0		1	0		H2		COM		1
		1	0		1	1		H3		COM		1
		1	1		0	0		H4		COM		1
		1	1		0	1		H5		COM		1
						0		H6				-
		1	1		1				-	COM		-
-h -	The A		elect one of four		1	1 es in SYNC-OU	T mode. (Refer to	H7 Selectable			ection )	J
-04:	The P		Select one of four		b <sub>5</sub>	b4	Clocks		Acquisitio	n nine se	501011.)	
				F	0	0	9	-				
				-	0	1	15	-				
				-	1	0	47	-				
				-				-				
				L	1	1	79					
r: The ccess oper by wer by r The	the Da High the up oyte of oyte to SYNC	ata register. The Byte bit (HB) is oper byte of the the Configurati be accessed w bit. When the	Configuration Re on register. The H ith the next write. SYNC bit is set, the	at <b>power-</b> a 8-bit mode gister in 8-l B bit will au The HB bit e SYNC pir	e (BW bit b <sub>1)</sub> bit mode. W utomatically t is cleared a n is program	hen this bit is so be cleared whe at <b>power-up.</b> med as an input	a don't care condi et and bit $b_{12} = 0$ n data is written to and the converter	, the next b the upper b is in synchro	yte written byte of the	to the AD Configurat e. In this m	C12048 w tion registe	is bit is used rill program er, allowing ng edge on
7: The ccess oper by wer by 3: The YNC p synchr	the Da the High the up oyte of oyte to SYNC oin cau ronous	ata register. The Byte bit (HB) is oper byte of the the Configurati be accessed w C bit. When the uses the ADC to a mode. In this	SE bit is cleared meaningful only in Configuration Re on register. The H ith the next write. SYNC bit is set, the hold the input sign mode the signal at	at <b>power-</b> a 8-bit mode gister in 8-l B bit will au The HB bit e SYNC pir nal and beg	e (BW bit b <sub>1;</sub> bit mode. W utomatically t is cleared a n is program gin a convers	hen this bit is so be cleared whe at <b>power-up.</b> med as an input sion. When b <sub>15</sub> o	et and bit $b_{12} = 0$ n data is written to	, the next b the upper b is in synchro pin is progra	yte written byte of the phous mod ammed as	to the AD Configurat e. In this m an output a	C12048 w tion registen node a risi and the co	is bit is used rill program er, allowing ng edge on onverter is in
The ccess oper by wer by The YNC p synchr YNC b	the Da High the up byte of byte to SYNC bin cau ronous bit is s	ata register. The Byte bit (HB) is oper byte of the the Configurati be accessed w bit. When the uses the ADC to mode. In this et at <b>power-up</b>	e SE bit is cleared meaningful only in Configuration Re on register. The H ith the next write. SYNC bit is set, th hold the input sign mode the signal at	at <b>power-</b> a 8-bit mode gister in 8-l B bit will au The HB bit e SYNC pir nal and beg t the SYNC	e (BW bit b <sub>1)</sub> bit mode. W utomatically t is cleared a n is programi gin a convers pin indicate	hen this bit is so be cleared whe at <b>power-up.</b> med as an input sion. When $b_{15}$ of the status of t	et and bit $b_{12} = 0$ n data is written to and the converter cleared, the SYNC the converter. The	, the next b the upper b is in synchro pin is progra SYNC pin is	yte written byte of the phous mod ammed as s high whe	to the AD Configurat e. In this m an output a n a conver	C12048 w tion registen node a risi and the co	is bit is used rill program er, allowing ng edge on onverter is in
The ccess oper by wer by The YNC p synchr YNC b	the Da High the up byte of oyte to SYNC bin cau ronous bit is s	ata register. The Byte bit (HB) is oper byte of the the Configurati be accessed w be accessed w bit. When the ses the ADC to mode. In this et at <b>power-up</b> command field.	e SE bit is cleared meaningful only in Configuration Re on register. The H ith the next write. SYNC bit is set, th hold the input sign mode the signal at	at <b>power-</b> a 8-bit mode gister in 8-l B bit will au The HB bit e SYNC pir nal and beg t the SYNC	e (BW bit b <sub>1)</sub> bit mode. W utomatically t is cleared a n is programi gin a convers pin indicate	hen this bit is so be cleared whe at <b>power-up.</b> med as an input sion. When b <sub>15</sub> of the status of the of the ADC120	et and bit $b_{12} = 0$ n data is written to and the converter cleared, the SYNC	, the next b the upper b is in synchro pin is progra SYNC pin is	yte written byte of the phous mod ammed as s high whe	to the AD Configurat e. In this m an output a n a conver	C12048 w tion registen node a risi and the co	is bit is used rill program er, allowing ng edge on onverter is in
The ccess oper by wer by The YNC p synchr YNC b 11-bg: b10	the Da High the up oyte of oyte to SYNC oin cau ronous bit is s <b>:</b> The <b>10 b</b>	ata register. The Byte bit (HB) is pper byte of the the Configurati be accessed w bit. When the ses the ADC to a mode. In this et at <b>power-up</b> command field. <b>9</b>	<ul> <li>SE bit is cleared meaningful only in configuration Re on register. The H ith the next write.</li> <li>SYNC bit is set, th hold the input sign mode the signal at .</li> <li>These bits select</li> </ul>	at <b>power</b> - a 8-bit mode gister in 8- B bit will au The HB bit e SYNC pir nal and beg t the SYNC	e (BW bit b <sub>1)</sub> ; bit mode. W utomatically t is cleared a n is program in a convers pin indicate of operation	hen this bit is so be cleared whe at <b>power-up.</b> med as an input sion. When b <sub>15</sub> c is the status of t of the ADC120	et and bit b <sub>12</sub> = 0 n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> vali <b>Command</b>	, the next b the upper b is in synchro pin is progra SYNC pin is	yte written byte of the phous mod ammed as s high whe	to the AD Configurat e. In this m an output a n a conver	C12048 w tion registen node a risi and the co	is bit is used rill program er, allowing ng edge on onverter is in
The ccess oper by wer by The YNC p ynchr YNC b 11-bg: b10 0	the Da High the up byte of byte to SYNC bit is s bit is s <b>:</b> The	tata register. The Byte bit (HB) is byper byte of the the Configurati be accessed w C bit. When the ses the ADC to a mode. In this i en ande. In this i a mode. In this i a mo	e SE bit is cleared meaningful only in Configuration Re on register. The H ith the next write. SYNC bit is set, th hold the input sign mode the signal at These bits select	at <b>power</b> - a 8-bit mode gister in 8- B bit will au The HB bit e SYNC pir nal and beg t the SYNC	e (BW bit b <sub>1)</sub> ; bit mode. W utomatically t is cleared a n is program jin a convers pin indicate of operation	hen this bit is so be cleared whe at <b>power-up</b> . med as an input ison. When b <sub>15</sub> of s the status of f of the ADC120 or consumption r	et and bit b <sub>12</sub> = 0 n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> vale <b>Command</b> mode	, the next b the upper b is in synchri- pin is progra SYNC pin is ue is 000. (S	yte written byte of the proous mod ammed as s high whe Gee Note 2	to the AD Configurat e. In this m an output a n a conver 2)	C12048 w tion registen node a risi and the co	is bit is used rill program er, allowing ng edge on onverter is in
The ccess oper by wer by in The YNC p synchr YNC b 11-bg: b10 0	the Da e High the up oyte of oyte to e SYNC bin cau ronous bit is s <b>:</b> The <b>0</b> (0)	tata register. The Byte bit (HB) is byte of the the Configurati be accessed w 2 bit. When the isses the ADC to a mode. In this i et at <b>power-up</b> command field. 9 5 5 5 5 5 5 6 7 6 7 7 8 9 7 8 7 8 8 8 8 8 8 8 8 8 8 8 8 8	e SE bit is cleared meaningful only in Configuration Re on register. The H ith the next write. SYNC bit is set, th hold the input sign mode the signal at These bits select command. This puts mmand. This will co	at <b>power-</b> a 8-bit mode gister in 8- B bit will at The HB bit e SYNC pir nal and beg t the SYNC the mode a the ADC ir ause the AI	e (BW bit b <sub>1</sub> ) bit mode. W utomatically t is cleared a n is program in a convers pin indicate of operation <u>n a low powe</u> DC to perform	hen this bit is sibe cleared whe at <b>power-up.</b> med as an input sion. When b <sub>15</sub> ( s the status of 1 of the ADC120 pr consumption r m a self-calibrati	et and bit b <sub>12</sub> = 0 n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> vali <b>Command</b> node ing cycle that will c	, the next b the upper b is in synchro pin is progra SYNC pin is ue is 000. (S	yte written byte of the procus mod ammed as s high whe See Note 2	to the AD Configurat e. In this m an output a n a conver 2)	C12048 w tion registen node a risi and the co	is bit is used rill program er, allowing ng edge on onverter is in
The ccess oper by wer by inthe YNC p synchr YNC b inthe ynC b inthe i i i i i i i i i i i i i i i i i i i	the Da High the up oyte of oyte to SYNC oin cau ronous bit is s <b>:</b> The <b>10 b</b> <b>0</b> (0)	tata register. The Byte bit (HB) is opper byte of the sopper byte of the the Configurati be accessed w be accessed w be twhen the sees the ADC to mode. In this et at <b>power-up</b> command field. <b>9</b> 0 Standby cc Ful-Cal co 0 Auto-zero	a SE bit is cleared meaningful only in configuration Re on register. The H ith the next write. SYNC bit is set, th hold the input sig mode the signal at These bits select ommand. This puts mmand. This will command. Th	at power- a 8-bit mode gister in 8- B bit will au The HB bit e SYNC pir nal and beg t the SYNC the mode s the ADC ir ause the AI Il cause the	e (BW bit b <sub>1</sub> ) bit mode. W utomatically t is cleared a n is program gin a convers pin indicate of operation <u>n a low powe</u> DC to perform a ADC to perform	hen this bit is sibe cleared whe at <b>power-up</b> . med as an input sion. When b <sub>15</sub> d s the status of i of the ADC1200 er consumption r m a self-calibrati	et and bit b <sub>12</sub> = 0 n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> vale <b>Command</b> mode	, the next b the upper b is in synchro pin is progra SYNC pin is ue is 000. (S	yte written byte of the procus mod ammed as s high whe See Note 2	to the AD Configurat e. In this m an output a n a conver 2)	C12048 w tion registen node a risi and the co	is bit is used rill program er, allowing ng edge on onverter is in
The ccess oper by wer by The YNC p ynchr YNC b 11-bg: b10 0 0 1	the Date of the uppyte of opyte to synce of sync	tata register. The Byte bit (HB) is opper byte of the be ported the Configurati be accessed w be the Configurati be accessed w be the ADC toc mode. In this set at <b>power-up</b> command field. <b>9</b> <b>0</b> Standby cr Ful-Cal co <b>0</b> Auto-zero Reset com	a SE bit is cleared meaningful only in o Configuration Re on register. The H ith the next write. SYNC bit is set, th hold the input sign mode the signal at These bits select mmand. This puts mmand. This will co command. This will mand. This puts th	at power- a 8-bit mode gister in 8-1 B bit will at The HB bit e SYNC pir nal and beg t the SYNC the mode s the ADC ir ause the AI Il cause the AI the ADC in a	e (BW bit b1) bit mode. W utomatically it is cleared a is program gin a convers pin indicate of operation n a low powe DC to perforn ADC to perforn un idle mode.	hen this bit is sibe cleared whe at <b>power-up.</b> med as an input sion. When b <sub>15</sub> c is the status of f of the ADC1200 rr consumption r m a self-calibration form an auto-zer	et and bit b <sub>12</sub> = 0 n data is written to and the converter to cleared, the SYNC the converter. The 48. <b>Power-up</b> value <b>Command</b> mode ing cycle that will c o cycle that correct	, the next b the upper b is in synchrr pin is progra SYNC pin is ue is 000. (S orrect linear ts offset err	yte written pyte of the pnous mod ammed as a high whe see Note 2 cose and zero prs.	to the AD Configurat e. In this m an output a n a conver 2)	C12048 w lion registe and the cc rsion is tal	is bit is used ill program ar, allowing ng edge on nverter is ir king place.
r: The ccess oper by wer by s: The YNC p synchr YNC b 11-bg: b10 0 0	the Date of the uppyte of opyte to e SYNC opin cauronous bit is s to the transmission of transmisa	tata register. The Byte bit (HB) is opper byte of the sopper byte of the the Configurati be accessed w be accessed w be twhen the sees the ADC to mode. In this et at <b>power-up</b> command field. <b>9</b> 0 Standby cc Ful-Cal co 0 Auto-zero 1 Reset corr will immed	SE bit is cleared meaningful only in to Configuration Re on register. The H ith the next write. SYNC bit is set, th hold the input sign mode the signal at . These bits select mmand. This puts mmand. This will c command. This will c the mand. This will put the mand. This put the	at power- a 8-bit mode gister in 8-l B bit will aut The HB bit e SYNC pir nal and beg t the SYNC i the mode e the ADC ir ause the AI Il cause the e ADC in a the convert he program	e (BW bit b <sub>1</sub> ) bit mode. W utomatically t is cleared a h is program in a converse pin indicate of operation h a low powe DC to perform ADC to perform ADC to perform in idle mode.	hen this bit is sibe cleared when at <b>power-up</b> . and as an input sion. When b <sub>15</sub> ( is the status of 1 of the ADC120 ar consumption r m a self-calibrat form an auto-zer mode, preparing	et and bit b <sub>12</sub> = 0 n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> vali <b>Command</b> node ing cycle that will c	, the next b the upper b is in synchro pin is progra SYNC pin is ue is 000. (S orrect linear ts offset erro	yte written prous mod ammed as s high whe See Note 2 ity and zero ors.	to the AD Configurat e. In this m an output a n a conver 2) o errors.	C12048 w tion registe node a risi and the cc rsion is tak	is bit is usee ill program r, allowing ng edge on nverter is ir ing place. <sup>-</sup>
The cccess         poper by           opper by         ys           ys: The p         ys           yNC p         ys           yn         p           yn <td< td=""><td>the Date of the up of the</td><td>tata register. The Byte bit (HB) is opper byte of the bopper byte of the the Configurati be accessed w bet. When the sees the ADC to sees the ADC to mode. In this let at <b>power-up</b> command field. <b>9</b> 0 Standby co Ful-Cal co 0 Auto-zero 1 Reset com will immed edge appe</td><td>a SE bit is cleared meaningful only in o Configuration Re on register. The H ith the next write. SYNC bit is set, th hold the input sig mode the signal at These bits select ommand. This select command. This will cu command. This will mand. This puts th nand. This will put tately begin after th ars on the SYNC p</td><td>at power- a 8-bit mode gister in 8- B bit will at The HB bit e SYNC pir- nal and beg t the SYNC t the mode t the SYNC t t the sync t t the sync t t the sync t t t the sync t t t the sync t t t the sync t t t t t the sync t t t t t t t t t t t t t t t t t t t</td><td>e (BW bit b<sub>1</sub>) bit mode. W utomatically t is cleared at is program in a conversi- pin indicate of operation a low powe DC to perforn ADC to perforn a ADC to perforn and low powe ter in a start imed acquisi</td><td>hen this bit is sibe cleared whe at <b>power-up.</b> med as an input sion. When b<sub>15</sub> d s the status of 1 of the ADC1200 or consumption r m a self-calibrati form an auto-zer mode, preparing tion time has en</td><td>et and bit b<sub>12</sub> = 0 n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> valie <b>Command</b> node ing cycle that will c to cycle that correct git to perform a cond ded. In synchronou</td><td>, the next b the upper b is in synchri- pin is progra SYNC pin is ue is 000. (\$ orrect linear ts offset erro- nversion. If i is mode (b<sub>b</sub></td><td>yte written yte of the onous mod ammed as s high whe see Note 2 cty and zero ors.</td><td>to the AD Configurat e. In this m an output a n a conver 2) o errors.</td><td>C12048 w tion registe node a risi and the cc rsion is tak e (b<sub>8</sub> = "C will begin</td><td>is bit is usee ill program r, allowing ng edge on nverter is in ving place '''), conversi after a rising</td></td<>	the Date of the up of the	tata register. The Byte bit (HB) is opper byte of the bopper byte of the the Configurati be accessed w bet. When the sees the ADC to sees the ADC to mode. In this let at <b>power-up</b> command field. <b>9</b> 0 Standby co Ful-Cal co 0 Auto-zero 1 Reset com will immed edge appe	a SE bit is cleared meaningful only in o Configuration Re on register. The H ith the next write. SYNC bit is set, th hold the input sig mode the signal at These bits select ommand. This select command. This will cu command. This will mand. This puts th nand. This will put tately begin after th ars on the SYNC p	at power- a 8-bit mode gister in 8- B bit will at The HB bit e SYNC pir- nal and beg t the SYNC t the mode t the SYNC t t the sync t t the sync t t the sync t t t the sync t t t the sync t t t the sync t t t t t the sync t t t t t t t t t t t t t t t t t t t	e (BW bit b <sub>1</sub> ) bit mode. W utomatically t is cleared at is program in a conversi- pin indicate of operation a low powe DC to perforn ADC to perforn a ADC to perforn and low powe ter in a start imed acquisi	hen this bit is sibe cleared whe at <b>power-up.</b> med as an input sion. When b <sub>15</sub> d s the status of 1 of the ADC1200 or consumption r m a self-calibrati form an auto-zer mode, preparing tion time has en	et and bit b <sub>12</sub> = 0 n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> valie <b>Command</b> node ing cycle that will c to cycle that correct git to perform a cond ded. In synchronou	, the next b the upper b is in synchri- pin is progra SYNC pin is ue is 000. (\$ orrect linear ts offset erro- nversion. If i is mode (b <sub>b</sub>	yte written yte of the onous mod ammed as s high whe see Note 2 cty and zero ors.	to the AD Configurat e. In this m an output a n a conver 2) o errors.	C12048 w tion registe node a risi and the cc rsion is tak e (b <sub>8</sub> = "C will begin	is bit is usee ill program r, allowing ng edge on nverter is in ving place '''), conversi after a rising
The ccess speer by speer	the Date of the up of the	tata register. The Byte bit (HB) is byper byte of the the Configurati be accessed w be accessed w accessed w	a SE bit is cleared meaningful only in to Configuration Re on register. The H ith the next write. SYNC bit is set, the hold the input sign mode the signal at the command. This sult command. This will command. This will command. This will put lately begin after the area on the SYNC p. W) bit. When this	at power- a 8-bit mode gister in 8-l B bit will aut The HB bit e SYNC pir- nal and beg t the SYNC the mode the SYNC the mode the ADC in a ause the AI II cause the AI II cause the the convert he program jn. bit is cleare	e (BW bit b <sub>1</sub> ) bit mode. W utomatically tis cleared an is program in a converse pin indicate of operation a low powe DC to perforn ADC to perforn ADC to perforn a ADC to perforn a ADC to perforn a dow powe ter in a start med acquisi ed the ADC	hen this bit is sibe cleared when the power-up. med as an input sion. When b <sub>15</sub> ( s the status of 1 of the ADC120 r consumption r m a self-calibrati form an auto-zer mode, preparing tion time has en 12048 is configu	et and bit b <sub>12</sub> = 0 n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> vali <b>Command</b> node ing cycle that will c o cycle that correct g it to perform a coi ded. In synchronou rred to interface wi	, the next b the upper b is in synchri pin is progra SYNC pin is ue is 000. (\$ orrect linear ts offset errr version. If it is mode (b <sub>B</sub> th an 8-bit c	yte written yte of the onous mod ammed as s high whe See Note 2 (ty and zero ors. = "1"), cc ata bus; di	to the AD Configurat e. In this m an output a n a conver 2) o errors.	C12048 w tion registed and the cc rsion is take $(b_8 = "C$ will begin $_7-D_0$ are	is bit is usee ill program ar, allowing ng edge on nverter is ir ing place '''), conversi after a rising active and p
The ccess speer by were by speer by speer by speer by speer by spectrum speed of the speed	the Date of the up of the	tata register. The Byte bit (HB) is byper byte of the the Configurati be accessed w be accessed w accessed w	a SE bit is cleared meaningful only in to Configuration Re on register. The H ith the next write. SYNC bit is set, the hold the input sign mode the signal at the command. This sult command. This will command. This will command. This will put lately begin after the area on the SYNC p. W) bit. When this	at power- a 8-bit mode gister in 8-l B bit will aut The HB bit e SYNC pir- nal and beg t the SYNC the mode the SYNC the mode the ADC in a ause the AI II cause the AI II cause the the convert he program jn. bit is cleare	e (BW bit b <sub>1</sub> ) bit mode. W utomatically tis cleared an is program in a converse pin indicate of operation a low powe DC to perforn ADC to perforn ADC to perforn a ADC to perforn a ADC to perforn a dow powe ter in a start med acquisi ed the ADC	hen this bit is sibe cleared when the power-up. med as an input sion. When b <sub>15</sub> ( s the status of 1 of the ADC120 r consumption r m a self-calibrati form an auto-zer mode, preparing tion time has en 12048 is configu	et and bit b <sub>12</sub> = 0 n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> valie <b>Command</b> node ing cycle that will c to cycle that correct git to perform a cond ded. In synchronou	, the next b the upper b is in synchri pin is progra SYNC pin is ue is 000. (\$ orrect linear ts offset errr version. If it is mode (b <sub>B</sub> th an 8-bit c	yte written yte of the onous mod ammed as s high whe See Note 2 (ty and zero ors. = "1"), cc ata bus; di	to the AD Configurat e. In this m an output a n a conver 2) o errors.	C12048 w tion registed and the cc rsion is take $(b_8 = "C$ will begin $_7-D_0$ are	is bit is usee ill program ar, allowing ng edge on nverter is ir ing place '''), conversi after a rising active and p
: The ccess oper by wer by ; The YNC p synchr YNC b 11-b9: 0 0 1 1 0 0 1 1 0 0 0 0 0 0 0 0 0 0 0	the Date of the up of the	tata register. The Byte bit (HB) is byper byte of the the Configurati be accessed w bit. When the ses the ADC to command field. 9 0 Standby co Ful-Cal co 0 Auto-zero 1 Reset com 0 Start comr will immed ende appe the Bus Width (E TRI-STATE. W	a SE bit is cleared meaningful only in Configuration Re on register. The H ith the next write. SYNC bit is set, th hold the input signode the signal at . These bits select "These bits select mmand. This will command. This will command. This will put iately begin after that ars on the SYNC p W) bit. When this //hen the BW bit is //hen the BW bit is //hen the SW bit is //hen the SW bit select is a set of the set o	at power- a 8-bit mode gister in 8-l B bit will aut The HB bit e SYNC pir- nal and beg t the SYNC the mode the SYNC the mode the ADC in a ause the AI II cause the AI II cause the the convert he program jn. bit is cleare	e (BW bit b <sub>1</sub> ) bit mode. W utomatically tis cleared an is program in a converse pin indicate of operation a low powe DC to perforn ADC to perforn ADC to perforn a ADC to perforn a ADC to perforn a dow powe ter in a start med acquisi ed the ADC	hen this bit is sibe cleared when the power-up. med as an input sion. When b <sub>15</sub> ( s the status of 1 of the ADC120 r consumption r m a self-calibrati form an auto-zer mode, preparing tion time has en 12048 is configu	et and bit b <sub>12</sub> = 0 n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> vali <b>Command</b> node ing cycle that will c o cycle that correct g it to perform a coi ded. In synchronou rred to interface wi	, the next b the upper b is in synchri pin is progra SYNC pin is ue is 000. (\$ orrect linear ts offset errr version. If it is mode (b <sub>B</sub> th an 8-bit c	yte written yte of the onous mod ammed as s high whe See Note 2 (ty and zero ors. = "1"), cc ata bus; di	to the AD Configurat e. In this m an output a n a conver 2) o errors.	C12048 w tion registed and the cc rsion is take $(b_8 = "C$ will begin $_7-D_0$ are	is bit is usee ill program ar, allowing ng edge on nverter is ir ing place '''), conversi after a rising active and p
: The ccess oper by wer by f: The fYNC p synchr fYNC b h(1-bg: b) 0 0 1 1 1 0 0 0 0 0 0 0 0 0 0 0 0 0 0	the Date of the up of the	Atta register. The Byte bit (HB) is opper byte of the sopper byte of the the Configurati be accessed w be the Configurati be accessed w be the Configurati be accessed w be the Configurati be accessed w be the Configuration of the Configurat	a SE bit is cleared meaningful only in Configuration Re on register. The H ith the next write. SYNC bit is set, th hold the input sigmode the signal at . These bits select . These bits select command. This puts mmand. This puts th nand. This puts th nand. This puts that altely begin after that are on the SYNC p W) bit. When this //hen the BW bit is //y/	at power- 8-bit mode gister in 8-B B bit will au The HB bit e SYNC pir- nal and beget t the SYNC t the mode t t the SYNC t t the mode t t t t SYNC t t t t t t t t t t t t t t t t t t t	e (BW bit b <sub>1</sub> ) bit mode. W utomatically is cleared a is program in a converse pin indicate of operation n a low powe DC to perform ADC to perform ADC to perform ADC to perform a converse in a low powe a converse in a low powe in a low powe in a converse in a converse	hen this bit is sibe cleared whe at <b>power-up</b> . med as an input sion. When b <sub>15</sub> d s the status of 1 of the ADC120 mer consumption r m a self-calibrat form an auto-zer mode, preparing tion time has en 12048 is configu	et and bit b <sub>12</sub> = 0 n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> vali <b>Command</b> node ing cycle that will c o cycle that correct g it to perform a coi ded. In synchronou rred to interface wi	, the next b the upper b is in synchri- pin is progra SYNC pin is use is 000. (S orrect linear ts offset erri- niversion. If it is mode (b <sub>B</sub> th an 8-bit c data bus ar	yte written yte of the phous mod ammed as is high whe Gee Note 2 ity and zero ors.	to the AD Configurat e. In this m an output a n a conver 2) o errors. o errors. e o errors. ata pins D s b 13-D0 i	C12048 w tion register node a risi and the cc rsion is tak e (b <sub>8</sub> = "C will begin 7-D <sub>0</sub> are all act	is bit is used ill program or, allowing ng edge on nyerter is in ving place '''), conversi after a rising active and p we. The BW
: The ccess s pper by wer by : The fYNC b i: The fyNC b i:	the Date of the up of the	tata register. The Byte bit (HB) is boper byte of the beaccessed with Configurati be accessed with configurati be accessed with the configurati be accessed with a configuration beaccessed with the set at power-up command field. 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9	a SE bit is cleared meaningful only in to Configuration Re on register. The H ith the next write. SYNC bit is set, the hold the input sign mode the sign at the sector of the sector	at power- a - bit mode gister in 8-1 B bit will au The HB bit e SYNC pir- nal and beg t the SYNC at the SYNC t the mode t the SYNC at the ADC in ause the AI I cause the ause the ADC in a the program bit is cleare set, the AD e 12-bit + s	e (BW bit b <sub>1</sub> ) bit mode. W utomatically tis cleared at n is program in a converse pin indicate of operation a low powe DC to perforn a ADC to perforn a ADC to perforn a ADC to perforn a ADC to perforn a data converse ter in a start med acquisi ed the ADC1 CC12048 is converse	hen this bit is sibe cleared when the power-up. med as an input sion. When b <sub>15</sub> is s the status of 1 of the ADC120 r consumption r m a self-calibrati form an auto-zer mode, preparing tion time has en 12048 is configu onfigured to inter-	et and bit b <sub>12</sub> = 0 n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> vali <b>Command</b> node ing cycle that will c to cycle that will c to cycle that correct g it to perform a coi ded. In synchronou rred to interface wi arface with a 16-bit	, the next b the upper b is in synchri pin is progra SYNC pin is ue is 000. (S orrect linear ts offset error nversion. If in smode (b <sub>8</sub> th an 8-bit c data bus ar m. All reads	yte written yte of the phous mod ammed as is high whe Gee Note 2 ity and zero ors.	to the AD Configurat e. In this m an output a n a conver 2) o errors. o errors. e o errors. ata pins D s b 13-D0 i	C12048 w tion registen node a risi and the cc rsion is tak e (b <sub>8</sub> = ''C will begin 7-D <sub>0</sub> are are all act ADC1204	is bit is used ill program or, allowing ng edge on nyerter is in ving place '''), conversi after a rising active and p we. The BW
The ccess oper by were by service by servic	the Date of the up of the	tata register. The Byte bit (HB) is boper byte of the beaccessed with configurati be accessed with configurati be accessed with the configurati be accessed with a configuration beaccessed with the set at power-up command field. 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9	a SE bit is cleared meaningful only in to Configuration Re on register. The H ith the next write. SYNC bit is set, the hold the input sign mode the sign at the sector of the sector	at power- a - bit mode gister in 8-1 B bit will au The HB bit e SYNC pir- nal and beg t the SYNC at the SYNC t the mode t the SYNC at the ADC in ause the AI I cause the ause the ADC in a the program bit is cleare set, the AD e 12-bit + s	e (BW bit b <sub>1</sub> ) bit mode. W utomatically tis cleared at n is program in a converse pin indicate of operation a low powe DC to perforn a ADC to perforn a ADC to perforn a ADC to perforn a ADC to perforn a data converse ter in a start med acquisi ed the ADC1 CC12048 is converse	hen this bit is sibe cleared when the power-up. med as an input sion. When b <sub>15</sub> is s the status of 1 of the ADC120 r consumption r m a self-calibrati form an auto-zer mode, preparing tion time has en 12048 is configu onfigured to inter-	et and bit b <sub>12</sub> = 0 n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> vali <b>Command</b> mode ing cycle that will c o cycle that correct g it to perform a conded. In synchronou red to interface with a 16-bit o's compliment for	, the next b the upper b is in synchri pin is progra SYNC pin is ue is 000. (S orrect linear ts offset error nversion. If in smode (b <sub>8</sub> th an 8-bit c data bus ar m. All reads	yte written yte of the phous mod ammed as is high whe Gee Note 2 ity and zero ors.	to the AD Configurat e. In this m an output a n a conver 2) o errors. o errors. e o errors. ata pins D s b 13-D0 i	C12048 w tion register node a risi and the cc rsion is tak e (b <sub>8</sub> = "C will begin 7-D <sub>0</sub> are all act	is bit is used ill program or, allowing ng edge on nyerter is in ving place '''), conversi after a rising active and p we. The BW
The ccess soper by were by some	the Date of the up of the	Atta register. The Byte bit (HB) is byper byte of the the Configurati be accessed w be accessed w be the Configurati be accessed w be accessed w be accessed w be accessed w be accessed w be accessed w be accessed w accessed	a SE bit is cleared meaningful only in to Configuration Re on register. The H ith the next write. SYNC bit is set, the hold the input sign mode the sign at the sector of the sector	at power- a - bit mode gister in 8-1 B bit will au The HB bit e SYNC pir- nal and beg t the SYNC at the SYNC t the mode t the SYNC at the ADC in ause the AI I cause the ause the ADC in a the program pin. bit is cleare set, the AD e 12-bit + s	e (BW bit b <sub>1</sub> ) bit mode. W utomatically it is cleared a n is program in a converse pin indicate of operation n a low powe DC to perfor ADC to perfor a det ne ADC DC12048 is c	hen this bit is sibe cleared when the power-up. med as an input sion. When b <sub>15</sub> is s the status of 1 of the ADC120 r consumption r m a self-calibrati form an auto-zer mode, preparing tion time has en 12048 is configu onfigured to inter-	et and bit b <sub>12</sub> = 0 n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> vali <b>Command</b> mode ing cycle that will c o cycle that correct g it to perform a conded. In synchronou red to interface with a 16-bit o's compliment for	, the next b the upper b is in synchri pin is progra SYNC pin is ue is 000. (S orrect linear ts offset error nversion. If in smode (b <sub>8</sub> th an 8-bit c data bus ar m. All reads	yte written yte of the phous mod ammed as is high whe Gee Note 2 ity and zero ors.	to the AD Configurat e. In this m an output a n a conver 2) o errors. o errors. e o errors. ata pins D s b 13-D0 i	C12048 w tion registen node a risi and the cc rsion is tak e (b <sub>8</sub> = ''C will begin 7-D <sub>0</sub> are are all act ADC1204	is bit is used ill program or, allowing ng edge on nyerter is in ving place '''), conversi after a rising active and p we. The BW
The ccess soper by were by some	the Date of the up of the	Atta register. The Byte bit (HB) is opper byte of the sopper byte of the the Configurati be accessed w bit. When the sees the ADC to a mode. In this is et at <b>power-up</b> command field. 9 9 0 5 tandby cr Ful-Cal co 0 0 4 uto-zero Reset com 0 0 5 start comr will immed edge appe the Bus Width (E TRI-STATE. V bower-up. TER (Read Only is register on t MSB b12 t	a SE bit is cleared meaningful only in to Configuration Re on register. The H ith the next write. SYNC bit is set, the hold the input sign mode the signal at the command. This sults select mmand. This puts mmand. This will command. This will command. This will put iately begin after the ars on the SYNC p W) bit. When this When the BW bit is will write that holds the data bus. When	at power- a - bit mode gister in 8-1 B bit will aut The HB bit e SYNC pir- nal and bege t the SYNC the mode the SYNC the mode the ADC in a ause the AL I cause the AL II cause the ADC in a the convert he con	e (BW bit b <sub>1</sub> ) bit mode. W utomatically tis cleared a n is program in a converse pin indicate of operation a low powe DC to perforn ADC to perforn ADC to perforn ADC to perforn ADC to perforn ADC to perforn ADC to perforn a de in a start med acquisi ed the ADC DC12048 is c	hen this bit is sibe cleared whe be cleared whe at <b>power-up</b> . med as an input sion. When b <sub>15</sub> ( s the status of 1 of the ADC120 in consumption in m a self-calibrati form an auto-zer mode, preparing tion time has en 12048 is configu onfigured to inter ion result in two ster in 8-bit mode p7 b <sub>6</sub>	et and bit b <sub>12</sub> = 0 n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> vali <b>Command</b> mode ing cycle that will c to cycle that will c to cycle that correct git to perform a co ded. In synchronout red to interface wi arface with a 16-bit o's compliment form le, the sign bit is e	, the next b the upper b is in synchri pin is progra SYNC pin is orrect linear ts offset erri rversion. If i is mode (b <sub>8</sub> th an 8-bit c data bus ar n. All reads xtended.	yte written yte of the phous mod ummed as s high whe see Note 2 ty and zero ors. asynchro = "1"), cc ata bus; d ad data pin- performed	to the AD Configurat e. In this m an output a n a conver 2) o errors.	C12048 w tion registend node a risi and the cc rsion is taken a (b <sub>8</sub> = "C will begin $_7$ -D <sub>0</sub> are are all act ADC1204:	is bit is used ill program or, allowing ng edge on nyerter is in ving place '''), conversi after a rising active and p we. The BW
The ccess oper by synchrony of the ccess oper by synchrony oper by synchrony operations of the ccess oper by synchrony operations of the ccess operation operation operation operations operation operations oper	the Da be High the up yoy of by yoy of both the up yoy of the up yoy of both the up yoy of the up yoy of both the up yoy of the up yoy of the up yoy of the up yoy of the up yoy of the up yoy of the up yoy of the up yoy of the up yoy of the up yoy of the up yoy of th	tata register. The Byte bit (HB) is opper byte of the sopper byte of the the Configurati be accessed w bit. When the sees the ADC to mode. In this is et at <b>power-up</b> command field. 9 9 0 5 tandby cr Ful-Cal co 0 0 4 uto-zero 1 Reset com 0 0 5 standby cr Reset com 0 0 5 standby cr Reset com 0 0 5 start com will immed edge appe the Bus Width (E TRI-STATE. V bower-up. TER (Read Only reg is register on t MSB b12 tag	a SE bit is cleared meaningful only in to Configuration Re on register. The H ith the next write. SYNC bit is set, the hold the input sign mode the signal at the command. This sults select mmand. This puts mmand. This will command. This will command. This will put iately begin after the ars on the SYNC p W) bit. When this When the BW bit is will write that holds the data bus. When	at power- a - bit mode gister in 8-1 B bit will aut The HB bit e SYNC pir- nal and bege t the SYNC the mode the SYNC the mode the ADC in a ause the AL I cause the AL II cause the ADC in a the convert he con	e (BW bit b <sub>1</sub> ) bit mode. W utomatically tis cleared a n is program in a converse pin indicate of operation a low powe DC to perforn ADC to perforn ADC to perforn ADC to perforn ADC to perforn ADC to perforn ADC to perforn a de in a start med acquisi ed the ADC DC12048 is c	hen this bit is sibe cleared whe be cleared whe at <b>power-up</b> . med as an input sion. When b <sub>15</sub> ( s the status of 1 of the ADC120 in consumption in m a self-calibrati form an auto-zer mode, preparing tion time has en 12048 is configu onfigured to inter ion result in two ster in 8-bit mode p7 b <sub>6</sub>	et and bit $b_{12} = 0$ n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> vali <b>Command</b> mode ing cycle that will c to cycle that correct pit to perform a cond ded. In synchronou rred to interface wi arface with a 16-bit c's compliment for le, the sign bit is e b_5 b_4	, the next b the upper b is in synchri pin is progra SYNC pin is orrect linear ts offset erri rversion. If i is mode (b <sub>8</sub> th an 8-bit c data bus ar n. All reads xtended.	yte written yte of the phous mod ummed as s high whe see Note 2 ty and zero ors. asynchro = "1"), cc ata bus; d ad data pin- performed	to the AD Configurat e. In this m an output a n a conver 2) o errors.	C12048 w tion registend node a risi and the cc rsion is taken a (b <sub>8</sub> = "C will begin $_7$ -D <sub>0</sub> are are all act ADC1204:	is bit is used ill program or, allowing ng edge on nyerter is in ving place '''), conversi after a rising active and p we. The BW
transformed by the second	the Da be High the up yoyte of by yoyte to be SYNC bit is s consumer of the synchronic transmission of the synchronic bit is s consumer of the synchronic bit is s consumer of the synchronic bit is so the synchronic test of test of the synchronic test of test	tata register. The Byte bit (HB) is opper byte of the sopper byte of the the Configurati be accessed w be accessed w accessed w acc	a SE bit is cleared meaningful only in Configuration Re on register. The H ith the next write. SYNC bit is set, th hold the input sig mode the signal at These bits select mmand. This will constrained mmand. This puts mmand. This puts mmand. This will put iately begin after th ars on the SYNC p W) bit. When this /hen the BW bit is //p sister that holds the he data bus. When D11 b10	at power- a b-bit mode gister in 8- B bit will at The HB bit e SYNC pir nal and beg t the SYNC the mode the SYNC the mode the ADC in ause the AI Il cause the AI Il cause the AI Il cause the ADC in ause the ADC in a the convert he program bit is clear set, the AD bit is clear set, the AD bit is clear set, the AD	e (BW bit b <sub>1</sub> ) bit mode. W utomatically it is cleared a is programm gin a converse pin indicate of operation n a low powe DC to perfor ADC to perfor ADC to perfor ADC to perfor a dide mode. ter in a start med acquisi ed the ADC CC12048 is c sign convers he data regis	hen this bit is sibe cleared whe at <b>power-up</b> . med as an input sion. When b <sub>15</sub> ( s the status of 1 of the ADC120 in consumption in m a self-calibrati form an auto-zer mode, preparing tion time has en 12048 is configu onfigured to inter ion result in two ster in 8-bit mode procession and the second procession and the second pro	et and bit $b_{12} = 0$ n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> vali <b>Command</b> mode ing cycle that will c to cycle that correct pit to perform a cond ded. In synchronou red to interface with a 16-bit c's compliment for le, the sign bit is e b_5 b_4 ion Data	, the next b the upper b is in synchri pin is progra SYNC pin is orrect linear ts offset erri rversion. If i is mode (b <sub>8</sub> th an 8-bit c data bus ar n. All reads xtended.	yte written yte of the phous mod ummed as s high whe see Note 2 ty and zero ors. asynchro = "1"), cc ata bus; d ad data pin- performed	to the AD Configurat e. In this m an output a n a conver 2) o errors.	C12048 w tion registend node a risi and the cc rsion is taken a (b <sub>8</sub> = "C will begin $_7$ -D <sub>0</sub> are are all act ADC1204:	is bit is used ill program or, allowing ng edge on nyerter is in ving place '''), conversi after a rising active and p we. The BW
transformed and a second	the D: a High the upyte of byte to a SYNC bit is s bit is s c The b) c (c) bit is s c The c (c) c (c)	tata register. The Byte bit (HB) is opper byte of the sopper byte of the the Configurati be accessed w be accessed w be tweether the configurati be accessed w be accessed w accessed w acces	<ul> <li>SE bit is cleared meaningful only in Configuration Re on register. The H ith the next write.</li> <li>SYNC bit is set, the hold the input sigmode the signal at .</li> <li>These bits select</li> <li>Dommand. This puts mmand. This puts the mand. This puts the analy begin after that are on the SYNC p W) bit. When this //hen the BW bit is</li> <li>Inter that holds the data bus. When t</li></ul>	at power- a to power- a 8-bit mode gister in 8-B b bit will au The HB bit e SYNC pir nal and beget t the SYNC t the mode t the SYNC t t the SYNC t t the SYNC t t t t S CON t t S CON t t S CON t S CON	e (BW bit b <sub>1</sub> ) bit mode. W utomatically tis cleared a is cleared a is program in a conversion in a conversion n a low powe DC to perform ADC to perform AD	hen this bit is sibe cleared when at <b>power-up</b> . med as an input sion. When b <sub>15</sub> c is the status of 1 of the ADC120 mr consumption r m a self-calibrati form an auto-zer mode, preparing tion time has en 12048 is configu onfigured to inter ion result in two ster in 8-bit mode ter in	et and bit $b_{12} = 0$ n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> vali <b>Command</b> mode ing cycle that will c to cycle that will c to cycle that correct jit to perform a cond ded. In synchronol inde interface wi red to interface wi reface with a 16-bit b's compliment for- le, the sign bit is e b_5 b_4 ion Data	, the next b the upper b is in synchri pin is progra SYNC pin is orrect linear ts offset erri rversion. If i is mode (b <sub>8</sub> th an 8-bit c data bus ar n. All reads xtended.	yte written yte of the phous mod ummed as s high whe see Note 2 ty and zero ors. asynchro = "1"), cc ata bus; d ad data pin- performed	to the AD Configurat e. In this m an output a n a conver 2) o errors.	C12048 w tion registend node a risi and the cc rsion is taken a (b <sub>8</sub> = "C will begin $_7$ -D <sub>0</sub> are are all act ADC1204:	is bit is used ill program or, allowing ng edge on nyerter is in ving place '''), conversi after a rising active and p we. The BW
7: The ccess pper by synchra ynch far ync b ync b ync bri yn	the D: a High the upyte of byte to a SYNC bit is s bit is s c The b) c (c) bit is s c The c (c) c (c)	tata register. The Byte bit (HB) is opper byte of the sopper byte of the the Configurati be accessed w be accessed w be tweether the configurati be accessed w be accessed w accessed w acces	a SE bit is cleared meaningful only in Configuration Re on register. The H ith the next write. SYNC bit is set, th hold the input sig mode the signal at These bits select mmand. This will constrained mmand. This puts mmand. This puts mmand. This will put iately begin after th ars on the SYNC p W) bit. When this /hen the BW bit is //p sister that holds the he data bus. When D11 b10	at power- a to power- a 8-bit mode gister in 8-B b bit will au The HB bit e SYNC pir nal and beget t the SYNC t the mode t the SYNC t t the SYNC t t the SYNC t t t t S CON t t S CON t t S CON t S CON	e (BW bit b <sub>1</sub> ) bit mode. W utomatically tis cleared a is cleared a is program in a conversion in a conversion n a low powe DC to perform ADC to perform AD	hen this bit is sibe cleared when at <b>power-up</b> . med as an input sion. When b <sub>15</sub> c is the status of 1 of the ADC120 mr consumption r m a self-calibrati form an auto-zer mode, preparing tion time has en 12048 is configu onfigured to inter ion result in two ster in 8-bit mode ter in	et and bit $b_{12} = 0$ n data is written to and the converter cleared, the SYNC the converter. The 48. <b>Power-up</b> vali <b>Command</b> mode ing cycle that will c to cycle that will c to cycle that correct jit to perform a cond ded. In synchronol inde interface wi red to interface wi reface with a 16-bit b's compliment for- le, the sign bit is e b_5 b_4 ion Data	, the next b the upper b is in synchri pin is progra SYNC pin is orrect linear ts offset erri rversion. If i is mode (b <sub>8</sub> th an 8-bit c data bus ar n. All reads xtended.	yte written yte of the phous mod ummed as s high whe see Note 2 ty and zero ors. asynchro = "1"), cc ata bus; d ad data pin- performed	to the AD Configurat e. In this m an output a n a conver 2) o errors.	C12048 w tion registend node a risi and the cc rsion is taken a (b <sub>8</sub> = "C will begin $_7$ -D <sub>0</sub> are are all act ADC1204:	is bit is used ill program or, allowing ng edge on nyerter is in ving place '''), conversi after a rising active and p we. The BW

# **Functional Description**

The ADC12048 is programmed through a digital interface that supports an 8-bit or 16-bit data bus. The digital interface consists of a 13-bit data input/output bus (D<sub>12</sub>-D<sub>0</sub>), digital control signals and two internal registers: a **write** only 13-bit **Configuration** register and a **read** only 13-bit **Data** register.

The Configuration register programs the functionality of the ADC12048. The 13 bits of the Configuration register are divided into 7 fields. Each field controls a specific function of the ADC12048: the channel selection of the MUX, the acquisition time, synchronous or asynchronous conversions, mode of operation and the data bus size.

## **Features and Operating Modes**

## SELECTABLE BUS WIDTH

The ADC12048 can be programmed to interface with an 8-bit or 16-bit data bus. The BW bit (b<sub>12</sub>) in the Configuration register controls the bus size. The bus width is set to **8 bits** (D<sub>7</sub>-D<sub>0</sub> are active and D<sub>12</sub>-D<sub>8</sub> are in TRI-STATE) if the BW bit is cleared or **13 bits** (D<sub>12</sub>-D<sub>0</sub> are active) if the BW bit is set. At **power-up** the bus width defaults to 8 bits and any initial programming of the ADC12048 should take this into consideration.

In 8-bit mode the Configuration register is byte accessible. The HB bit in the lower byte of the Configuration register is used to access the upper byte. If the HB bit is set with a write to the lower byte, the next byte written to the ADC will be placed in the upper byte of the Configuration register. After data is written to the upper byte of the Configuration register, the HB bit will automatically be cleared, causing the next byte written to the ADC to go to the lower byte of the Configuration register. When reading the ADC in 8-bit mode, the first read cycle places the lower byte of the Data register on the data bus followed by the upper byte during the next read cycle.

In **13-bit** mode the HB bit is a don't care condition and all bits of the data register and Configuration register are accessible with a single read or write cycle. Since the bus width of the ADC12048 defaults to 8 bits after power-up, the first action when 13-bit mode is desired must be set to the bus width to 13 bits.

## WMODE

The WMODE pin is used to determine the active edge of the write pulse. The state of this pin determines which edge of the  $\overline{WR}$  signal will cause the ADC to latch in data. This is processor dependent. If the processor has valid data on the bus during the falling edge of the  $\overline{WR}$  signal, the WMODE pin must be tied to  $V_D^+$ . This will cause the ADC to latch the data on the falling edge of the  $\overline{WR}$  signal. If data is valid on the rising edge of the  $\overline{WR}$  signal, the WMODE pin must be tied to DGND causing the ADC to latch in the data on the rising edge of the  $\overline{WR}$  signal.

## INPUT MULTIPLEXER

The ADC12048 has an eight channel input multiplexer with a COM input that can be used in a single-ended, pseudo-differential or fully-differential mode. The MUX select bits ( $b_3$ - $b_0$ ) in the Configuration register determine which channels will appear at the MUXOUT+ and MUXOUT- multiplexer output pins. (Refer to Register Bit Description Section.) Analog signal conditioning with fixed-gain amplifiers, programmable-gain amplifiers, filters and other processing circuits

can be used at the output of the multiplexer before being applied to the ADC inputs. The ADCIN+ and ADCIN- are the fully differential non-inverting (positive) and inverting (negative) inputs to the analog-to-digital converter (ADC) of the ADC12048. If no external signal conditioning is required on the signal output of the multiplexer, MUXOUT+ should be connected to ADCIN+ and MUXOUT- should be connected to ADCIN-.

The analog input multiplexer can be set up to operate in either one of eight differential or eight single-ended (the COM input as the zero reference) modes. In the differential mode, the analog inputs are paired as follows: CH0 with CH1, CH2 with CH3, CH4 with CH5 and CH6 with CH7. The input channel pairs can be connected to the MUXOUT+ and MUXOUT- pins in any order. In the single-ended mode, one of the input channels, CH0 through CH7, can be assigned to MUXOUT+ while the MUXOUT- is always assigned to the COM input.

## STANDBY MODE

The ADC12048 has a low power consumption mode (75  $\mu W$  @5V). This mode is entered when a Standby command is written in the command field of the Configuration register. A logic low appearing on the  $\overline{STDBY}$  output pin indicates that the ADC12048 is in the Standby mode. Any command other than the Standby command written to the Configuration register will get the ADC12048 out of the Standby mode. The  $\overline{STDBY}$  pin will immediately switch to a logic "1" as soon as the ADC12048 is requested to get out of the standby mode. The  $\overline{RDY}$  pin will then be asserted low when the ADC is actually out of the Standby mode and ready for normal operation. The ADC12048 defaults to the Standby mode following a hardware **power-up**. This can be verified by examining the logic low status of the STDBY pin.

#### SYNC/ASYNC MODE

The ADC12048 may be programmed to operate in synchronous (SYNC-IN) or asynchronous (SYNC-OUT) mode. To enter synchronous mode, the SYNC bit in the Configuration register must be set. The ADC12048 is in synchronous mode after a hardware **power-up**. In this mode, the SYNC pin is programmed as an input and conversions are synchronized to the rising edges of the signal applied at the SYNC pin. Acquisition time can also be controlled by the SYNC signal when in synchronous mode. Refer to the syncin timing diagrams. When the SYNC bit is cleared, the ADC is in asynchronous mode and the SYNC pin is programmed as an output. In asynchronous mode, the signal at the SYNC pin indicates the status of the converter. This pin is high when the converter is performing a conversion. Refer to the sync-out timing diagrams.

#### SELECTABLE ACQUISITION TIME

The ADC12048's internal sample/hold circuitry samples an input voltage by connecting the input to an internal sampling capacitor (approximately 70 pF) through an effective resistance equal to the multiplexer "On" resistance ( $300\Omega$  max) plus the "On" resistance of the analog switch at the input to the sample/hold circuit ( $2500\Omega$  typical) and the effective output resistance of the source. For conversion results to be accurate, the period during which the sampling capacitor is connected to the source (the "acquisition time") must be long enough to charge the capacitor to within a small fraction of an LSB of the input voltage. An acquisition time of 750 ns is sufficient when the external source resistance is

## Features and Operating Modes (Continued)

less than 1 k $\Omega$  and any active or reactive source circuitry settles to 12 bits in less than 500 ns. When source resistance or source settling time increase beyond these limits, the acquisition time must also be increased to preserve precision.

In asynchronous (SYNC-OUT) mode, the acquisition time is controlled by an internal counter. The minimum acquisition period is 9 clock cycles, which corresponds to the nominal value of 750 ns when the clock frequency is 12 MHz. Bits  $b_4$  and  $b_5$  of the Configuration Register are used to select the acquisition time from among four possible values (9, 15, 47, or 79 clock cycles). Since acquisition time in the asynchronous mode is based on counting clock cycles, it is also inversely proportional to clock frequency:

$$T_{ACQ}(\mu s) = rac{\text{number of clock cycles}}{f_{CLK} (MHz)}$$

Note that the actual acquisition time will be longer than  $T_{ACQ}$  because acquisition begins either when the multiplexer channel is changed or when  $\overline{RDY}$  goes low, if the multiplexer channel is not changed. After a read is performed,  $\overline{RDY}$  goes high, which starts the  $T_{ACQ}$  counter (see *Figure 7*).

In synchronous (SYNC-IN) mode, bits  $b_4$  and  $b_5$  are ignored, and the acquisition time depends on the sync signal applied at the SYNC pin. If a new MUX channel is selected at the start of the conversion, the acquisition period begins on the active edge of the  $\overline{WR}$  signal that latches in the new MUX channel (see *Figure 7*). If no new MUX channel is selected, the acquisition period begins on the falling edge of  $\overline{RDY}$ , which occurs at the end of the previous conversion (or at the end of an autozero or autocalibration procedure). The acquisition period ends when SYNC goes high.

To estimate the acquisition time necessary for accurate conversions when the source resistance is greater than 1 k $\Omega$ , use the following expression:

$$T_{\text{ACQMIN}} (\mu s) = \frac{0.75(\text{R}_{\text{S}} + \text{R}_{\text{M}} + \text{R}_{\text{S}/\text{H}})}{1 \text{ k}\Omega + \text{R}_{\text{M}} + \text{R}_{\text{S}/\text{H}}}$$
$$= \frac{0.75(\text{R}_{\text{S}} + 2800)}{3800}$$

where  $R_S$  is the source resistance,  $R_M$  is the MUX "On" resistance, and  $R_{S/H}$  is the sample/hold "On" resistance. If the settling time of the source is greater than 500 ns, the acquisition time should be about 300 ns longer than the settling time for a "well-behaved", smooth settling charac-

#### FULL CALIBRATION CYCLE

teristic.

A full calibration cycle compensates for the ADC's linearity and offset errors. The converter's DC specifications are guaranteed only after a full calibration has been performed. A full calibration cycle is initated by writing a Ful-Cal command to the ADC12048. During a full calibration, the offset error is measured eight times, averaged and a correction coefficient is created. The offset correction coefficient is stored in an internal offset correction register.

The overall linearity correction is achieved by correcting the internal DAC's capacitor mismatches. Each capacitor is compared eight times against all remaining smaller value capacitors. The errors are averaged and correction coefficients are created.

Once the converter has been calibrated, an arithmetic logic unit (ALU) uses the offset and linearity correction coefficients to reduce the conversion offset and linearity errors to within guaranteed limits.

## AUTO-ZERO CYCLE

During an auto-zero cycle, the offset is measured only once and a correction coefficient is created and stored in an internal offset register. An auto-zero cycle is initiated by writing an Auto-Zero command to the ADC12048.

## DIGITAL INTERFACE

The digital control signals are CS, RD, WR, RDY and STDBY. Specific timing relationships are associated with the interaction of these signals. Refer to the Digital Timing Diagrams section for detailed timing specifications. The active low RDY signal indicates when a certain event begins and ends. It is recommended that the ADC12048 should only be accessed when the RDY signal is low. It is in this state that the ADC12048 is ready to accept a new command. This will minimize the effect of noise generated by a switching data bus on the ADC. The only exception to this is when the ADC12048 is in the standby mode at which time the RDY is high and the STDBY signal is low. The ADC12048 is in the standby mode at power up or when a STANDBY command is issued. A Ful-Cal, Auto-Zero, Reset or Start command will get the ADC12048 out of the standby mode. This may be observed by monitoring the status of the RDY and STDBY signals. The RDY signal will go low and the STDBY signal high when the ADC12048 leaves the standby mode.

The following describes the state of the digital control signals for each programmed event in both 8-bit and 13-bit mode. RDY should be low before each command is issued except for the case when the device is in standby mode.

### FUL-CAL OR AUTO-ZERO COMMAND

*8-bit* mode: The first write to the ADC12048 will place the data in the lower byte of the Configuration register. This byte must set the HB bit (b<sub>7</sub>) to allow access to the upper byte of the Configuration register during the next write cycle. During the second write cycle, the Ful-Cal or Auto-Zero command must be issued. The edge of the second write pulse on the WR pin will force the RDY signal high. At this time the converter begins executing a full calibration or auto-zero cycle. The RDY signal will automatically go low when the full calibration or auto-zero cycle is done.

13-bit mode: In a single write cycle the Ful-Cal or Auto-Zero command must be written to the ADC12048. The edge of the  $\overline{WR}$  signal will force the  $\overline{RDY}$  high. At this time the converter begins executing a full calibration or auto-zero cycle. The  $\overline{RDY}$  signal will automatically go low when the full calibration or auto-zero cycle is done.

## STARTING A CONVERSION: START COMMAND

In order to completely describe the events associated with the Start command, both the SYNC-OUT and SYNC-IN modes must be considered.

#### SYNC-OUT/Asynchronous

*8-bit* mode: The first byte written to the ADC12048 should set the MUX channel, the acquisition time and the HB bit. The second byte should clear the SYNC bit, write the START command and clear the BW bit. In order to initiate a

## Features and Operating Modes (Continued)

conversion, two reads must be performed from the ADC12048. The rising edge of the second read pulse will force the RDY pin high and begin the programmed acquisition time selected by bits  $b_5$  and  $b_4$  of the configuration register. The SYNC pin will go high indicating that a conversion sequence has begun following the end of the acquisition period. The RDY and SYNC signal will fall low when the conversion is done. At this time new information, such as a new MUX channel, acquisition time and operational command can be written into the configuration register or it can remain unchanged. Assuming that the START command is in the Configuration register, the previous conversion can be read. The first read places the lower byte of the conversion result contained in the Data register on the data bus. The second read will place the upper byte of the conversion result stored in the Data register on the data bus. The rising edge on the second read pulse will begin another conversion sequence and raise the RDY and SYNC signals appropriately.

13-bit mode: The MUX channel and the acquisition time should be set, the SYNC bit cleared and the START command issued with a single write to the ADC12048. In order to initiate a conversion, a single read must be performed from the ADC12048. The rising edge of the read signal will force the RDY signal high and begin the programmed acquisition time selected by bits b5 and b4 of the configuration register. The SYNC pin will go high indicating that a conversion sequence has begun following the end of the acquisition period. The RDY and SYNC signal will fall low when the conversion is done. At this time new information, such as a new MUX channel, acquisition time and operational command can be written into the configuration register or it can remain unchanged. With the START command in the Configuration register, a read from the ADC12048 will place the entire 13-bit conversion result stored in the data register on the data bus. The rising edge of the read pulse will immediately force the  $\overline{\text{RDY}}$  output high. The SYNC will then go high following the elapse of the programmed acquisition time in the configuration register's bits b5 and b4.

#### SYNC-IN/Synchronous

For the SYNC-IN case, it is assumed that a series of SYNC pulses at the desired sampling rate are applied at the SYNC pin of the ADC12048.

*8-bit* mode: The first byte written to the ADC12048 should set the MUX channel and the HB bit. The second byte should set the SYNC bit, write the START command and clear the BW bit.

A rising edge on the SYNC pin or the second rising edge of two consecutive reads from the ADC12048 will force the  $\overline{\text{RDY}}$  signal high. It is recommended that the action of reading from the ADC12048 (not the rising edge of the SYNC signal) be used to raise the  $\overline{\text{RDY}}$  signal. In the SYNC-IN mode, only the rising edge of the SYNC signal will begin a conversion cycle. The rising edge of the SYNC also ends the acquisition period. The acquisition period begins following a write cycle containing MUX channel information. The selected MUX channel is sampled after the rising edge of the  $\overline{\text{WR}}$  signal until the rising edge of the SYNC pulse, at which time the signal will be held and conversion begins. The  $\overline{\text{RDY}}$  signal will go low when the conversion is done. A new MUX channel and/or operational command may be written into the Configuration register at this time, if needed. Two consecutive read cycles are required to retrieve the entire 13-bit conversion result from the ADC12048's data register. The first read will place the lower byte of the conversion result contained in the Data register on the data bus. The second read will place the upper byte of the conversion result stored in the Data register on the data bus. With the START command in the configuration register, the rising edge of the second read pulse will raise the  $\overline{\text{RDY}}$  signal high and begin a conversion cycle following a rising edge on the SYNC pin.

13-bit mode: The MUX channel should be selected, the SYNC bit should be set and the START command issued with a single write to the ADC12048. A rising edge on the SYNC pin or on the RD pin will force the RDY signal high. It is recommended that the action of reading from the ADC12048 (not the rising edge of the SYNC signal) be used to raise the  $\overline{\text{RDY}}$  signal. This will ensure that the conversion result is read during the acquisition period of the next conversion cycle, eliminating a read from the ADC12048 while it is performing a conversion. Noise generated by accessing the ADC12048 while it is converting may degrade the conversion result. In the SYNC-IN mode, only the rising edge of the SYNC signal will begin a conversion cycle. The RDY signal will go low when the conversion cycle is done. The acquisition time is controlled by the SYNC signal. The acquisition period begins following a write cycle containing MUX channel information. The selected MUX channel is sampled after the rising edge of the  $\overline{WR}$  signal until the rising edge of the SYNC pulse, at which time the signal will be held and conversion begins. A new MUX channel and/or operational command may be written into the Configuration register at this time, if needed. With the START command in the Configuration register, a read from the ADC12048 will place the entire conversion result stored in the Data register on the data bus and the rising edge of the read pulse will force the RDY signal high. The selected MUX channel will be sampled until a rising edge appears on the SYNC pin, at which the time sampled signal will be held and a conversion cycle started.

## STANDBY COMMAND

*8-bit* mode: The first byte written to the ADC12048 should set the HB bit in the Configuration register (bit  $b_7$ ). The second byte must issue the Standby command (bits  $b_{11}$ ,  $b_{10}$ ,  $b_9 = 0, 0, 0$ ).

13-bit mode: The Standby command must be issued to the ADC12048 in single write (bits  $b_{11}$ ,  $b_{10}$ ,  $b_9 = 0$ , 0, 0).

#### RESET

The RESET command places the ADC12048 into a ready state and forces the  $\overline{\text{RDY}}$  signal low. The RESET command can be used to interrupt the ADC12048 while it is performing a conversion, full-calibration or auto-zero cycle. It can also be used to get the ADC12048 out of the standby mode.

# Analog Application Information REFERENCE VOLTAGE

The ADC12048 has two reference inputs,  $V_{\text{REF}}^{+}$  and  $V_{\text{REF}}^{-}$ . They define the zero to full-scale range of the analog input signals over which 4095 positive and 4096 negative codes exist. The reference inputs can be connected to span the entire supply voltage range ( $V_{\text{REF}}^{-} = A\text{GND}$ ,  $V_{\text{REF}}^{+} = V_{\text{A}}^{+}$ ) or they can be connected to different voltages when other input spans are required. The reference inputs of the ADC12048 have transient capacitive switching currents. The voltage sources driving  $V_{\text{REF}}^{+}$  and  $V_{\text{REF}}^{-}$  must have very low output impedence and noise and must be adequately bypassed. The circuit in *Figure 8* is an example of a very stable reference source.

The ADC12048 can be used in either ratiometric or absolute reference appplications. In ratiometric systems, the analog



input voltage is proportional to the voltage used for the ADC's reference voltage. This technique relaxes the system reference requirements because the analog input voltage moves with the ADC's reference. The system power supply can be used as the reference voltage by connecting the V<sub>REF</sub><sup>+</sup> pin to V<sub>A</sub><sup>+</sup> and the V<sub>REF</sub><sup>-</sup> pin to AGND. For absolute accuracy, where the analog input voltage varies between very specific voltage limits, a time and temperature stable voltage source can be connected to the reference inputs. Typically, the reference voltage's magnitude will require an initial adjustment to null reference voltage induced full-scale errors.

The reference voltage inputs are not fully differential. The ADC12048 will not generate correct conversions if V<sub>REF</sub><sup>+</sup> – V<sub>REF</sub><sup>-</sup> is below 1V. *Figure 9* shows the allowable relationship between V<sub>REF</sub><sup>+</sup> and V<sub>REF</sub><sup>-</sup>.

# OUTPUT DIGITAL CODE VERSUS ANALOG INPUT VOLTAGE

The ADC12048's fully differential 12-bit  $\pm\,$  sign ADC generates a two's complement output that is found by using the equation shown below:

$$\text{Output code} = \frac{(V_{\text{IN}}^{+} - V_{\text{IN}}^{-}) \text{ (4096)}}{(V_{\text{REF}}^{+} - V_{\text{REF}}^{-})}$$

Round off the result to the nearest integer value between -4096 and 4095.



FIGURE 8. Low Drift Extremely Stable Reference Circuit

Part Number	Output Voltage Tolerance	Temperature Coefficient		
LM4041CI-Adj	$\pm 0.5\%$	±100ppm/°C		
LM4040AI-4.1	±0.1%	±100ppm/°C		
LM9140BYZ-4.1	$\pm 0.5\%$	±25ppm/°C		
LM368Y-5.0	±0.1%	±20ppm/°C		
Circuit of Figure 8	Adjustable	±2ppm/°C		

## Analog Application Information (Continued) INPUT CURRENT

At the start of the acquisition window ( $t_{AcqSYNOUT}$ ) a charging current (due to capacitive switching) flows through the analog input pins (CH0–CH7, ADCIN+ and ADCIN–, and the COM). The peak value of this input current will depend on the amplitude and frequency of the input voltage applied, the source impedance and the input switch ON resistance. With the MUXOUT+ connected to the ADCIN+ and the MUXOUT- connected to the ADCIN– the on resistance is typically 2800 $\Omega$ . Bypassing the MUX and using just the ADCIN+ and ADCIN- inputs the on resistance is typically 2500 $\Omega$ .

For low impedance voltage sources (1000 <  $\Omega$  for 12 MHz operation), the input charging current will decay to a value that will not introduce any conversion errors before the end of the default sample-and-hold (S/H) acquisition time (9 clock cycles). For higher source impedances (1000 >  $\Omega$  for 12 MHz operation), the S/H acquisition time should be increased to allow the charging current to settle within specified limits. In asynchronous mode, the acquisition time may be increased to 15, 47 or 79 clock cycles. If different acquisition times are needed, the synchronous mode can be used to fully control the acquisition time.

## INPUT BYPASS CAPACITANCE

External capacitors (0.01  $\mu$ F-0.1  $\mu$ F) can be connected between the analog input pins (CH0-CH7) and the analog ground to filter any noise caused by inconductive pickup associated with long leads.

## POWER SUPPLY CONSIDERATIONS

Decoupling and bypassing the power supply on a high resolution ADC is an important design task. Noise spikes on the V<sub>A</sub><sup>+</sup> (analog supply) or V<sub>D</sub><sup>+</sup> (digital supply) can cause conversion errors. The analog comparator used in the ADC will respond to power supply noise and will make erroneous conversion decisions. The ADC is especially sensitive to power supply spikes that occur during the auto-zero or linearity calibration cycles.

The ADC12048 is designed to operate from a single +5V power supply. The separate supply and ground pins for the analog and digital portions of the circuit allow separate external bypassing. To minimize power supply noise and ripple, adequate bypass capacitors should be placed directly between power supply pins and their associated grounds. Both supply pins should be connected to the same supply source. In systems with separate analog and digital supplies, the ADC should be powered from the analog supply. At least a 10 µF tantalum electrolytic capacitor in parallel with a 0.1 µF monolithic ceramic capacitor is recommended for bypassing each power supply. The key consideration for these capacitors is to have low series resistance and inductance. The capacitors should be placed as close as physically possible to the supply and ground pins with the smaller capacitor closer to the device. The capacitors also should have the shortest possible leads in order to minimize series lead inductance. Surface mount chip capacitors are optimal in this respect and should be used when possible.

When the power supply regulator is not local on the board, adequate bypassing (a high value electrolytic capacitor) should be placed at the power entry point. The value of the capacitor depends on the total supply current of the circuits on the PC board. All supply currents should be supplied by the capacitor instead of being drawn from the external supply lines, while the external supply charges the capacitor at a steady rate.

The ADC has two  $V_D^+$  and DGND pins. It is recommended to use a 0.1  $\mu F$  plus a 10  $\mu F$  capacitor between pins 15 and 16 ( $V_D^+$ ) and 14 (DGND) and a 0.1  $\mu F$  capacitor between pins 28 ( $V_D^+$ ) and 1 (DGND) for the PLCC package. The respective pins for the SO package are 21 and 22 ( $V_D^+$ ) and 20 (DGND), 6 ( $V_D^+$ ) and 7 (DGND). The layout diagram in *Figure 10* shows the recommended placement for the supply bypass capacitors.

# PC BOARD LAYOUT AND GROUNDING CONSIDERATIONS

To get the best possible performance from the ADC12048, the printed circuit boards should have separate analog and digital ground planes. The reason for using two ground planes is to prevent digital and analog ground currents from sharing the same path until they reach a very low impedance power supply point. This will prevent noisy digital switching currents from being injected into the analog ground.

*Figure 10* illustrates a favorable layout for ground planes, power supply and reference input bypass capacitors. It shows a layout using a 44-pin PLCC socket and throughhole assembly. A similar approach should be used for the PQFP package.

The analog ground plane should encompass the area under the analog pins and any other analog components such as the reference circuit, input amplifiers, signal conditioning circuits, and analog signal traces.

The digital ground plane should encompass the area under the digital circuits and the digital input/output pins of the ADC12048. Having a continuous digital ground plane under the data and clock traces is very important. This reduces the overshoot/undershoot and high frequency ringing on these lines that can be capacitively coupled to analog circuitry sections through stray capacitances.

The AGND and DGND in the ADC12048 are not internally connected together. They should be connected together on the PC board right at the chip. This will provide the shortest return path for the signals being exchanged between the internal analog and digital sections of the ADC.

It is also a good design practice to have power plane layers in the PC board. This will improve the supply bypassing (an effective distributed capacitance between power and ground plane layers) and voltage drops on the supply lines. However, power planes are not as essential as ground planes are for satisfactory performance. If power planes are used, they should be separated into two planes and the area and connections should follow the same guidelines as mentioned for the ground planes. Each power plane should be laid out over its associated ground planes, avoiding any overlap between power and ground planes of different types. When the power planes are not used, it is recommended to use separate supply traces for the  $V_{\mbox{\scriptsize A}}{}^+$  and V<sub>D</sub><sup>+</sup> pins from a low impedance supply point (the regulator output or the power entry point to the PC board). This will help ensure that the noisy digital supply does not corrupt the analog supply.



When measuring AC input signals, any crosstalk between analog input/output lines and the reference lines (CH0–CH7, MUXOUT  $\pm$ , ADC IN  $\pm$ , V<sub>REF</sub> $^\pm$ ) should be minimized. Crosstalk is minimized by reducing any stray capacitance between the lines. This can be done by increasing the clearance between traces, keeping the traces as short as possible, shielding traces from each other by placing them on different sides of the AGND plane, or running AGND traces between them.

*Figure 10* also shows the reference input bypass capacitors. Here the reference inputs are considered to be differential. The performance improves by having a 0.1  $\mu$ F capacitor between the V<sub>REF</sub><sup>+</sup> and V<sub>REF</sub><sup>-</sup>, and by bypassing in a single ended reference is used, V<sub>REF</sub><sup>-</sup> is connected to AGND and only two capacitors are used between V<sub>REF</sub><sup>+</sup> and V<sub>REF</sub><sup>-</sup> (0.1  $\mu$ F + 10  $\mu$ F). It is recommended to directly connect the AGND side of these capacitors to the V<sub>REF</sub><sup>-</sup> instead of connecting V<sub>REF</sub><sup>-</sup> and the ground sides of the capacitors separately to the ground planes. This provides a significantly lower-impedance connection when using surface mount technology.





National does not assume any responsibility for use of any circuitry described, no circuit patent licenses are implied and National reserves the right at any time without notice to change said circuitry and specifications.