



COLOR TELEVISION RECEIVER

Chassis : S15A
Model: CK1438VR5X/VWT CK2073XR5X/VWT
CK1448VR5X/BWT CK2173VR5X/BWT
CK2085VR5X/BWT CK20E3VR5X/NWT
CK2185VR5S/AWT

SERVICE Manual

COLOR TELEVISION RECEIVER




CONTENTS

1. Precautions
2. Specifications and IC Data
3. Disassembly and Reassembly
4. Alignment and Adjustment
5. Troubleshooting
6. Exploded View and Parts List
7. Electric Parts List
8. Block Diagram
9. PCB Layout Diagram
10. Wiring Diagram
11. Schematic Diagrams



8. Block Diagram



8-1 S15A







11. Schematic Diagrams

11-1 ONECHIP




Schematic Diagrams


11-2 SOUND, EXT-A/V (Europe/Africa)



 : Power Line
 : Signal Line









11-3 SOUND, EXT-A/V (Middle East / Asia)






Schematic Diagrams


11-4 POWER / CRT / VERTICAL / HORIZONTAL




— : Power Line
— : Signal Line



11-5 MICOM (TTX)





Schematic Diagrams

11-6 MICOM (NON-TTX)

