TOSHIBA BIPOLAR LINEAR INTEGRATED CIRCUIT SILICON MONOLITHIC

TA1274F

PIF / SIF SYNCHRONOUS DEMODULATOR IC

FEATURES

• Compatible pin assignment to TA1267AF

PIF CIRCUIT

- True synchronous PIF demodulator
- 3-stages gain controlled PIF amplifier
- High speed response PIF AGC detector
- Buzz reducer
- Equalizer for video output
- AFT detector without extra reference circuit

SIF CIRCUIT

- Wide range gain controlled SIF amplifier (control range : 70dB typ.)
- Alignment-free PLL-FM demodulator



Weight: 0.27 g (typ.)

BLOCK DIAGRAM



TERMINAL FUNCTION

PIN No.	NAME	FUNCTION	INTERFACE CIRCUIT			
1 24	PIF input	Differential type inputs. Typical input level is 85 dBµV.				
2	RF AGC output	Open collector (PNP) type output. Maximum output current is 0.5 mA.				
3	AGC filter	Connect a capacitor (0.47 µF) between GND.				
4 5	EQ amplifier output EQ filter	No.4 terminal is EQ amplifier output. Maximum output current of this terminal is 5 mA. No.5 terminal is for EQ filter.				
6	N.C.		_			
7	Bias filter	Connect a capacitor (10 μF) between GND.				

PIN No.	NAME	FUNCTION	INTERFACE CIRCUIT				
8	EQ amplifier input	EQ amplifier inputs.					
9	APC filter	Connect a resister (330 Ω) and a capacitor (0.47 μ F) between GND in series. And connect a capacitor (1000 pF) between this terminal and GND. Sensitivity of phase detector is 400 μ A / rad (Typ.), and sensitivity of VCO is 1.8 MHz / V (Typ.).					
10	Video output	Connect a resister (1 kΩ) between GND. Maximum output current is 10 mA.					
11	2 nd SIF output	2 nd SIF signal is outputted from this terminal.	2 7 7 7 7 7 7 7 7 7 7 7 7 7				
12	FM demodulating filter	Connect a capacitor (2.2 μF) between GND.					

PIN No.	NAME	FUNCTION	INTERFACE CIRCUIT
13	RF AGC delay adj.	This terminal is for RF AGC delay point adjustment.100 μ A current is outputted from this terminal. Connect a resister (5.6 k Ω) and a volume (10 k Ω) between GND in series.	
14	AFT Defeat SW	This terminal is AFT defeat switch. To open this terminal, AFT function is activate. To connect GND this terminal, AFT function is not activate. And terminal No.20 goes to $1/2 V_{CC}$.	
15	(No function)	This terminal must be connected to V_{CC} .	—
16	2 nd SIF input	This terminal 2nd SIF input. This terminal must be decoupled outer circuit on D.C.	
17	AF output	Output resistance of this terminal is 7.5 k Ω .	21 7.5 kΩ 4 4 4 7.5 kΩ 4 4 7.5 kΩ 23 23 23 23 23 23 23 23 23 23
18 19	VCO tank	Connect tank for VCO between these terminals. Capacitance of the VCO tank is 27 pF.	

PIN No.	NAME	FUNCTION	INTERFACE CIRCUIT			
20	AFT output	Push-pull type current output. Reverse type AFT.				
21	V _{CC}	Recommended voltage range is 9.0 V ± 10%.	_			
22	SIF input	In use inter-carrier application, connect this terminal to GND. In this condition, the SIF amplifier sets gain minimum.				
23	GND	_	_			

MAXIMUM RATINGS (Ta = 25°C)

CHARACTERISTIC	SYMBOL	RATING	UNIT
Supply Voltage	V _{CC}	13	V
Power Dissipation	P _{D max}	1040 (Note 1)	mW
Operating Temperature	T _{opr}	-20~75	°C
Storage Temperature	T _{stg}	-55~150	°C

Note 1: This value is on condition that the IC is mounted on PCB (50 mm × 50 mm). When using the device at Ta = 25°C, decrease the power dissipation by 8.3 mW for each increase of 1°C.

RECOMMENDED SUPPLY VOLTAGE

PIN No.	PIN NAME	MIN	TYP.	MAX	UNIT
21	V _{CC}	8.1	9.0	9.9	V

ELECTRICAL CHARACTERISTICS

DC current characteristics (V_{CC} = 9.0 V, Ta = 25°C)

PIN No.	PIN NAME	SYMBOL	MIN	TYP.	MAX	UNIT
21	V _{CC}	ICC	36	45	60	mA

DC voltage characteristics ($V_{CC} = 9.0 V$, Ta = 25°C)

PIN No.	SYMBOL	TEST CIR- CUIT	TEST CONDITION	MIN	TYP.	MAX	UNIT
1	V ₁	-	—	3.5	4.0	4.5	
4	V ₄	-	No signal input	4.7	5.2	5.7	
5	V ₅	-	—	4.7	5.2	5.7	
7	V ₇	_	—	6.3	7.0	7.7	
10	V ₁₀	_	No signal input	4.7	5.2	5.7	
11	V ₁₁	_	—	3.1	3.5	3.9	
14	V ₁₄	_	—	2.5	3.1	3.7	
15	V ₁₅	_	_	2.5	3.1	3.7	V
16	V ₁₆	_	_	2.5	3.1	3.7	
17	V ₁₇	_	2nd SIF 4.5 MHz	3.2	3.7	4.2	
18	V ₁₈	_	—	7.2	7.6	7.9	
19	V ₁₉	_	_	7.2	7.6	7.9	
20	V ₂₀	—	In AFT defeat	4.3	4.5	4.7	
22	V ₂₂	—	_	4.9	5.3	5.7	
24	V ₂₄	—	_	3.5	4.0	4.5	

AC CHARACTERISTICS (V_{CC} = 9.0 V, Ta = 25°C) PIF section

CHARACTERISTIC	SYMBOL	TEST CIR- CUIT	TEST CONDITION	MIN	TYP.	MAX	UNIT
PIF Input Sensitivity	v _{in} min (p)	_			40	45	dBu\/
PIF Maximum Input Signal	v _{in} max (p)	—	(Note 1)	105	113	_	ubµv
PIF Gain Control Range	R _{AGC} (p)	_		68	73	_	dB
RF AGC Maximum Output Voltage	V _{AGC} max	_	(Noto 2)	8.5	8.9	_	V
RF AGC Minimum Output Voltage	V _{AGC} min	_	(Note 2)	_	0.0	0.1	V
PIF Input Resistance (*)	Z _{in} R (p)	_	(Noto 2)	_	1.2	_	kΩ
PIF Input Capacitance (*)	Z _{in} C (p)	_	(Note 3)	_	3.6	_	pF
Differential Gain	DG	_	(Note 4)	_	1.0	3.0	%
Differential Phase	DP	_	(Note 4)	_	3.0	5.0	deg
Intermodulation	١ _M	_	(Note 5)	50	55	_	dB
Video Output Signal Amplitude	v _{Det} (p)	_	(Note 6)	2.0	2.2	2.4	V
Video Output S / N	S / N (p)	_	(Note 7)	55	60	_	dB
Synchronous Signal Level	V _{sync}	_	(Note 8)	2.4	2.7	3.0	
Threshold Level of the Black Noise Inverter	V _{thB}	_	(Note 9)	1.7	2.0	2.3	V
Clamp Level of the Black Noise Inverter	V _{cpB}	_	(1018-9)	3.3	3.6	3.9	
Video Bandwidth (-3 dB)	f _{Det} (p)	_	(Note 10)	6	8	10	MHz
Capture Range of the PLL (Upper)	f _{р (р) Н}	_		1.8	2.3	—	
Capture Range of the PLL (Lower)	f _{p (p) L}	—	(Noto 11)	—	-2.0	-1.5	
Hold Range of the PLL (Upper)	f _{h (p) H}	_		1.8	2.3	_	
Hold Range of the PLL (Lower)	f _{h (p) L}	_			-2.0	-1.5	
Control Steepness of the VCO	β	_	(Note 12)		1.8	—	MHz / V
Steepness of the AFT Detection	S _{AFT}	-		20	25	30	kHz / V
AFT Maximum Output Voltage	V _{AFT} max	_	(Note 13)	8.5	8.8	_	
AFT Minimum Output Voltage	V _{AFT} min	_		—	0.4	0.6	V
AFT Output Voltage On Defeating	V _{AFT} Def	_	(Note 14)	4.3	4.5	4.7	

*: Not tested

SIF section

CHARACTERISTIC	SYMBOL	TEST CIR- CUIT	TEST CONDITION	MIN	TYP.	MAX	UNIT
SIF Maximum Input Signal	v _{in} max (s)	_	(Noto 15)	105	118		dBµV
SIF Gain Control Range	R _{AGC} (s)	—	(Note 13)	55	75	_	dB
SIF Input Resistance (*)	Z _{in} R (s)	_	(Noto 16)	_	10		kΩ
SIF Input Capacitance (*)	Z _{in} C (s)	—		_	2.8	_	pF
Limiting Sensitivity	v _{in} lim	—	(Note 17)	_	40	45	dBµV
AM Reduction Ratio	AMR	—	(Note 18)	55	68	_	dB
AF Output Signal Amplitude	V _{Det} (s)	_		350	500	710	mV _{rms}
AF Output S / N	S / N (s)	_	(Note 19)	55	63		dB
Total Harmonics Distortion	THD	—		_	0.2	1.0	%
Hold Range of the FM Demodulator (Lower)	f _h (s) L	_	(Noto 20)	_	_	3.9	MHz
Hold Range of the FM Demodulator (Upper)	f _h (s) H	_		5.3	_		
Capture Range of the FM Demodulator (Upper)	f _{p (s)} H	_	(Noto 21)	_	_	4.0	MHz
Capture Range of the FM Demodulator (Lower)	fp (s) L	_		5.2	_	_	
Ripple Rejection	RR	_	(Note 22)	_	_	-22	dB

*: Not tested

MEASUREMENTS

PIF section

								TES	COND	TION			
NOTE	INPUT POINT	MEAS. POINT	SW3	SW8	VR13		SW14 b				SW17	SW22	
Note 1	J1	TP10	OFF	ON	_		OFF				ON	ON	 Input the signal (Frequency : 45.75 MHz, Amplitude : 85 dBµV, 15 kHz sine wave / 30% AM) to J1.
													 Change amplitude of the input signal, and measure amplitude of the output signal at TP10.
													Calculate R _{AGC} (p) show as below.
													+ 1 dB Ref. level - 3 dB Vin min (p) RAGC (p) Vin max (p) - Input Amplitude
Note 2	J1	TP2	OFF	ON	Min. Max.		OFF				ON	ON	 Input the signal (Frequency : 45.75 MHz, Amplitude : 85 dBµV, 15 kHz sine wave / 30% AM) to J1. Set V_{R13} to the minimum. Measure voltage at TP 2 (V_{AGC} max V.) Set V_{R13} to the maximum. Measure voltage at TP 2 (V_{AGC} min V.)
Note 3	—	TP1 TP24	OFF	ON	-		OFF				ON	ON	 Remove all connections from terminal 1 and terminal 24. Measure resistance (Zin R (p) kΩ) and capacitance (Zin C (p) pF) of TP1 and TP24 by the impedance meter.

	TEST CONDITION															
NOTE	INPUT POINT	MEAS. POINT	SW3		SW8	VR13			SW14 b					SW17	SW22	
Note 4	J1	TP4	OFF		ON	—			OFF					ON	ON	 Input the signal (Frequency : 45.75 MHz, Amplitude : 85 dBµV, amplitude modulated by 10 step signal) to J1.
																Measure DG and DP at TP4.
Note 5	J1	TP4	OFF		ON	_			OFF					ON	ON	 Input the signal (Frequency : 45.75 MHz, Amplitude : 85 dBµV, 15 kHz sine wave / 30% AM) from J1.
																 Measure the minimum voltage of the output signal at TP4 (Vmin).
																• Input the mixture of 3 signals (signal 1 Frequency : 45.75 MHz, Amplitude : 85 dB μ V, signal 2 Frequency : 42.17 MHz, Amplitude : 75 dB μ V, and signal 3 Frequency : 41.25 MHz, Amplitude : 75 dB μ V) to J1.
																 Apply DC voltage to TP3 and adjust it so that the bottom of the output signal at TP4 is equal to Vmin.
																 Measure frequency spectrum of the output signal at TP4.
																Spectrum of TP4 Output
																920 KHZ 3.58 MHZ 4.5 MHZ
																- Requency

								TES	COND	TION			
NOTE	INPUT POINT	MEAS. POINT	SW3	SW8	VR13		SW14 b				SW17	SW22	
Note 6	J1	TP4	OFF	ON			OFF				ON	ON	 Input the signal (Frequency : 45.75 MHz, Amplitude : 85 dBµV, amplitude modulated by 100 IRE white picture) to J1.
													• Measure amplitude of the output signal at TP4 (VDet (p) V).
Note 7	J1	TP4	OFF	ON			OFF				ON	ON	 Input the signal (Frequency : 45.75 MHz, Amplitude : 85 dBµV, amplitude modulated by black picture) to J1.
													 Measure video S / N at TP4 (HPF : 100 kHz, LPF : 4.2 MHz, CCIR Weighted) (S / N (p) dB).
Note 8	J1	TP4	OFF	ON			OFF				ON	ON	 Input the signal (Frequency : 45.75 MHz, Amplitude : 85 dBµV, amplitude modulated by 100 IRE white picture) to J1.
													Measure voltage of the sync. tip at TP4 (vsync V)
Note 9	J1	TP4	OFF	ON			OFF				ON	ON	 Input the signal (Frequency : 45.75 MHz, Amplitude : 85 dBμV, 15 kHz triangle wave / 50% AM) to J1.
													 Apply DC voltage to TP3 and adjust it to get the waveform shown as below at TP4.
													Measure VthB V and VcpB V at TP4.
													GND

								TEST	CONDI	ΓΙΟΝ			
NOTE	INPUT POINT	MEAS. POINT	SW3	SW8	VR13		SW14 b				SW17	SW22	
Note 10	J1	TP4	OFF	ON			OFF				ON	ON	 Input the mixture of 2 signals (signal 1 Frequency : 45.75 MHz, Amplitude : 82 dBµV, signal 2 Frequency : 45.65 MHz, Amplitude : 69 dBµV to J1. Measure the minimum voltage of the output signal at TP4 (VoTP4). Apply DC voltage to TP3 and adjust it so that the minimum voltage of the output signal at TP4 is equal to VoTP4. Decrease frequency of the input signal at J1, and measure amplitude of the output signal at TP4. Measure f Det (p) show as below.

	TEST CONDITION															
NOTE	INPUT POINT	MEAS. POINT	SW3		SW8	VR13		SI	V14 b					SW17	SW22	
Note 11	J1	TP20	OFF		ON			C	DFF					ON	ON	 Input the signal (Frequency : 45.75 MHz, Amplitude : 85 dBµV) to J1. Sweep down the input signal frequency to 41.75 MHz, and sweep up to 49.75 MHz. Sweep down the input signal frequency to 45.75 MHz. Measure the voltage at TP20.
Note 12	TP9	Pin 18 Pin 19	OFF		ON			C	FF					ON	ON	 Set the FET probe which connected to the spectrum analyzer near by pin 18 or pin 19 (Don't touch the probe directly to pin 18 or to pin 19). Apply 4.3 V to TP9, and measure frequency of the VCO oscillation by the spectrum analyzer (f_{LVCO} MHz). Apply 4.7 V to TP9, and measure frequency of the VCO oscillation by the spectrum analyzer (f_{HVCO} MHz). β MHz / V = (f_{HVCO} - f_{LVCO}) / 0.4

	TEST CONDITION															
NOTE	INPUT POINT	MEAS. POINT	SW3		SW8	VR13			SW14 b					SW17	SW22	
Note 13	J1	TP20	OFF		ON	—			OFF					ON	ON	 Input the signal (Frequency : 45.75 MHz - 20 kHz, Amplitude : 85 dBµV) to J1.
																 Measure voltage at TP20 (V_HTP20 V).
																- Input the signal (Frequency : 45.75 MHz + 20 kHz, Amplitude : 85 dB $\mu V)$ to J1.
																 Measure voltage at TP20 (V_LTP20 V).
																• S AFT kHz / V = 40 / (V _H TP20 - V _L TP20)
																 Input the signal (Frequency : 45.75 MHz - 500 kHz, Amplitude : 85 dBµV) to J1.
																 Measure voltage at TP20 (V_{AFT} max V).
																 Input the signal (Frequency : 45.75 MHz + 500 kHz, Amplitude : 85 dBµV) to J1.
																 Measure voltage at TP20 (V_{AFT} min V).
Note 14	_	TP20	OFF		ON	_			ON					ON	ON	Measure voltage at TP20 (V _{AFT} Def V).

SIF section

								TEST	COND	ITION			
NOTE	INPUT POINT	MEAS. POINT	SW3	SW8	VR13		SW14 b				SW17	SW22	
Note 15	J1 J2	TP11	OFF	ON			OFF				ON	OFF	 Input the signal (Frequency : 45.75 MHz, Amplitude : 85 dBµV) to J1, and input the signal (Frequency : 41.25 MHz, Amplitude : 75 dBµV) to J2. Change the amplitude of the signal at J2, and measure amplitude of the output signal at TP11. ¹/₉
Note 16	_	TP22	ON	ON	_		OFF				ON	-	 Remove all connections from terminal 22. Measure resistance (Zin R (s) kΩ and capacitance (Zin C (s) pF) of TP1 and TP24 by the impedance meter.
Note 17	J3	TP17	ON	ON	_		OFF				ON	ON	 Input the signal (Frequency : 4.5 MHz, Amplitude : 100 dBµV, 400 Hz sine wave / 25 kHz Devi FM) to J3. Measure amplitude of the output signal at TP17 (voTP17). Measure the input signal amplitude when the output amplitude from TP17 becomes -3 dB of voTP17, by decreasing the input signal amplitude to J3 (vin lim dBµV).

								TEST	COND	TION			
NOTE	INPUT POINT	MEAS. POINT	SW3	SW8	VR13		SW14 b				SW17	SW22	
Note 18	J3	TP17	ON	ON	_		OFF				ON	ON	 Input the signal (Frequency : 4.5 MHz, Amplitude : 100 dBµV, 400 Hz sine wave / 25 kHz Devi FM) to J3. Measure amplitude of the output signal at TP17 (v_{FM}TP17 mVrms). Input the signal (Frequency : 4.5 MHz, Amplitude : 100 dBµV, 400 Hz sine wave / 30% AM) to J3. Measure amplitude of the output signal at TP17 (v_{AM}TP17 mVrms). AMR4.5 dB = 20log (v_{FM}TP17 / v_{AM}TP17)
Note 19	J3	TP17	ON	ON	_		OFF				ON	ON	 Input the signal (Frequency : 4.5 MHz, Amplitude : 100 dBµV, 400 Hz sine wave / 25 kHz Devi FM) to J3. Measure amplitude of the output signal at TP17 (vDet (s) 4.5L mVrms). Measure distortion of the TP17 output (THD4.5L %). Input the signal (Frequency : 4.5 MHz, Amplitude : 100 dBµV to J3. Measure amplitude of the output signal at TP17 (v_NTP17 mVrms). S / N4.5 = 20log (vDet (s) 4.5 / v_NTP17)
Note 20	J3	TP12	ON	ON			OFF				ON	ON	 Input the signal (Frequency : 4.5 MHz, Amplitude : 100 dBµV to J3. Change the frequency of the input signal, and measure voltage at TP12. Image: the frequency of the input signal, and measure voltage at TP12. Image: the frequency of the input signal for the input signal for the input signal.

								TEST	CONDI	TION			
NOTE	INPUT POINT	MEAS. POINT	SW3	SW8	VR13		SW14 b				SW17	SW22	
Note 21	J3	TP12	ON	ON	—		OFF				ON	ON	 Input the signal (Frequency : 1 MHz, Amplitude : 100 dBµV) to J3.
													 Increase frequency of the input signal.
													Measure voltage of TP12 (VTP120 V).
													Apply 5 V to TP12.
													Stop appling 5 V to TP12.
													Measure voltage of TP12 (VTP121 V).
													 Measure frequency of the input signal when VTP120 = VTP121 (f_{p (s) L} MHz).
													 Input the signal (Frequency : 10 MHz, Amplitude : 100 dBµV) to J3.
													Decrease frequency of the input signal.
													Measure voltage of TP12 (VTP122 V).
													Connect TP12 to GND.
													Open TP12.
													Measure voltage of TP12 (VTP123 V).
													 Measure frequency of the input signal when VTP122 = VTP123 (f_{p (s) H} MHz).
Note 22	J3	TP17	ON	ON	—		OFF				ON	ON	 Input the signal (DC 9 V + AC Frequency : 60 Hz, Amplitude : 100 mV_{p-p}) to V_{CC} terminal.
													 Input the signal (Frequency : 1 MHz, Amplitude : 100 dBµV) to J3.
													 Measure amplitude of TP17 (vTP17 mV_{p-p}).
													• RR dB = 20log (vTP17 / 100)

TEST CIRCUIT



APPLICATION CIRCUIT



PACKAGE DIMENSIONS



Weight: 0.27 g (typ.)

RESTRICTIONS ON PRODUCT USE

- TOSHIBA is continually working to improve the quality and reliability of its products. Nevertheless, semiconductor devices in general can malfunction or fail due to their inherent electrical sensitivity and vulnerability to physical stress. It is the responsibility of the buyer, when utilizing TOSHIBA products, to comply with the standards of safety in making a safe design for the entire system, and to avoid situations in which a malfunction or failure of such TOSHIBA products could cause loss of human life, bodily injury or damage to property.
 In developing your designs, please ensure that TOSHIBA products are used within specified operating ranges as set forth in the most recent TOSHIBA products specifications. Also, please keep in mind the precautions and conditions set forth in the "Handling Guide for Semiconductor Devices," or "TOSHIBA Semiconductor Reliability Handbook" etc..
- The TOSHIBA products listed in this document are intended for usage in general electronics applications (computer, personal equipment, office equipment, measuring equipment, industrial robotics, domestic appliances, etc.). These TOSHIBA products are neither intended nor warranted for usage in equipment that requires extraordinarily high quality and/or reliability or a malfunction or failure of which may cause loss of human life or bodily injury ("Unintended Usage"). Unintended Usage include atomic energy control instruments, airplane or spaceship instruments, transportation instruments, traffic signal instruments, combustion control instruments, medical instruments, all types of safety devices, etc.. Unintended Usage of TOSHIBA products listed in this document shall be made at the customer's own risk.
- The products described in this document are subject to the foreign exchange and foreign trade laws.
- The information contained herein is presented only as a guide for the applications of our products. No responsibility is assumed by TOSHIBA CORPORATION for any infringements of intellectual property or other rights of the third parties which may result from its use. No license is granted by implication or otherwise under any intellectual property or other rights of TOSHIBA CORPORATION or others.
- The information contained herein is subject to change without notice.